# System M and System D- Connected Wireless Switch 1-gang/2-gang

# Device user guide

Information about features and functionality of the device.

07/2024

### merten\*





# **Legal Information**

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

# **Table of Contents**

| Safety Information  | 4  |
|---|----|
| System M and System D- Connected Wireless Switch 1-gang/2-      |    |
| gang  |    |
| For your safety   |    |
| About the device  |    |
| Installing the device   |    |
| Changing the device from 1-gang to 2-gang                       |    |
| Quick Home Connect  |    |
| About Quick Home Connect  | 8  |
| Pairing Wireless switch with Multiwire micro module dimmer      | 9  |
| Pairing Wireless switch with Micro module light switch (Puck)   | 10 |
| Pairing Wireless switch with Micro module shades control (Puck) | 11 |
| Using the Wireless switch in Quick Home Connect                 | 11 |
| Resetting the device in Quick Home Connect                      | 13 |
| LED indications in Quick Home Connect                           | 13 |
| Troubleshooting in Quick Home Connect                           | 13 |
| Pairing the device  | 14 |
| Configuring the device  | 15 |
| Setting the device location                                     | 15 |
| Renaming the device   |    |
| Identifying the device  |    |
| Removing the device from the system                             |    |
| Resetting the device  |    |
| Using the device  |    |
| Switching operation   |    |
| Assigning an Action to a Push Button                            |    |
| Assigning a Moment to the Push Button                           |    |
| Removing configured Action/Moment                               |    |
| Replacing the battery   |    |
| LED indications   |    |
| Troubleshooting   |    |
| Technical Data  | 25 |

# **Safety Information**

## Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that accompany this symbol to avoid possible injury or death.

### **AADANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

Failure to follow these instructions will result in death or serious injury.

### **AWARNING**

**WARNING** indicates a hazardous situation which, if not avoided, **could result** in death or serious injury.

### **ACAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

## **NOTICE**

NOTICE is used to address practices not related to physical injury.

# System M and System D- Connected Wireless Switch 1-gang/2-gang



MEG5001-0300 (System M)



MEG5001-6000 (System D)

# For your safety

## **ADANGER**

#### HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

While installing the device on a wall box or an existing switch outlet combination, always isolate the 230 V AC cables by applying an adhesive silver foil on the fixing plate.

Failure to follow these instructions will result in death or serious injury.

### About the device

The Connected Wireless Switch 1-gang/2-gang (hereinafter referred to as **Wireless switch**/ **Free Located switch**) is a battery-powered wireless push button switch that is used to control a group of Zigbee devices (such as light/shutter) within the same Zigbee network.

The device can be configured through the Wiser Home app.

#### Advantage of using a Wireless switch:

- Easy to use and user-friendly interface: also good for children (placed lower on the wall) and for the elderly who may not be so familiar with smart phones.
- · Easy to install on the wall: no wiring required.
- Easy to control in places where you wouldn't normally be able to install switches.

#### Features of a Wireless switch:

- Using the app, you can add various Actions (such as lighting/shutter control) to the Wireless switch.
- Using the app, you can add a Moment to the Wireless switch (such as Movie Night MOMENT/Good Night MOMENT).
- Low battery notification in the app.

#### NOTE:

- This device user guide shows pairing, configuration and other features of connected Wireless switch 2-gang. The same applies for connected Wireless switch 1-gang.
- Construction materials may cause interference which affect Hub-todevice and device-to-device distances. In the open air, there is no interference, so the distance can be much longer.
- Wireless switch can be used as part of Quick Home Connect room control solution.

# Installing the device

Refer to the installation instruction supplied with this product.

# Changing the device from 1-gang to 2-gang

You can change the Wireless switch mode from 1-gang to 2-gang before you pair your device to the **Hub**.

**NOTE:** The Wireless switch is in 1-gang mode by default.

Follow the steps to change the mode:

1. Remove the 1-gang rocker from the module.

### **NOTICE**


#### **MODULE DAMAGE**

The module is locked into the rocker. Use a screwdriver and carefully remove the rocker from the module.

Failure to follow these instructions can result in equipment damage.

- 2. Mount the 2-gang rocker on the module.
- 3. Insert the module into the frame from the front and ensure that it clicks into place.
- 4. Press and hold the top right and bottom left push button simultaneously for 10 seconds until the LED starts blinking red.

The red LED indicates the switching process. The Wireless switch is now changed to 2-gang mode.




**NOTE:** To change the mode back to 1-gang, reset the device, page 19 and replace with 1-gang rocker.

### **Quick Home Connect**

### **About Quick Home Connect**

Quick Home Connect is a wireless connectivity solution for Zigbee devices without the need for a Hub or smartphone application. Quick Home Connect is your starting point for wireless home automation. It performs functions like switching, dimming and shutter control using the Connected Wireless Switch (hereinafter referred to as Wireless switch) via a Zigbee network.

The **Wireless switch** is a battery-powered wireless push-button switch that is used to control Zigbee devices (such as dimmer) within the same Zigbee network.



### Supported devices

- Wiser Multiwire Micro Module LED Dimmer
- · Wiser Micro Module Light Switch
- · Wiser Micro Module Shades Control

#### Limitations


- · Quick Home Connect serves only as a room control solution.
- In a 1-gang Wireless switch, you cannot combine lighting and shutter control. However, with a 2-gang Wireless switch, you can use one gang for dimming/switching and the other for shutter control, or vice versa.
- This solution does not support remote control, smartphone app usage, or scheduling features.

## Pairing Wireless switch with Multiwire micro module dimmer

**Prerequisites**: While connecting the dimmer to the push buttons, make sure that the terminal 1 of the dimmer is wired to the left push button, and terminal 2 of the dimmer is wired to the right push button.

 Short press the push button 5 times in quick succession on the Wireless switch.

The status LED blinks green.



2.

# **AWARNING**

#### HAZARD OF ELECTRIC SHOCK

- Observe the regulations for working on live parts.
- Only actuate the device buttons using insulated auxiliary equipment that meets the requirements of EN 60900.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow either of the options to pair the Dimmer:

- Short press the Setup/Reset button 5 times in quick succession on the Dimmer.
- Short press the left push button (Wired to terminal 1) 5 times in quick succession.

The status LED blinks green on the Dimmer.

**NOTE:** If the Dimmer is located behind the mechanical push-button, the status LED is not visible.




The light connected to the Dimmer blinks for a few times. The status LED stops blinking green on the Wireless switch and the Dimmer. The Dimmer can now be controlled by the Wireless switch.

# Pairing Wireless switch with Micro module light switch (Puck)

 Short press the upper push-button 5 times in quick succession on the Wireless switch.

The status LED blinks green.



2.

### **AWARNING**

#### HAZARD OF ELECTRIC SHOCK

- Observe the regulations for working on live parts.
- Only actuate the device buttons using insulated auxiliary equipment that meets the requirements of EN 60900.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow either of the options to pair Puck:

- Short press the Setup/Reset button 5 times in quick succession on the Puck with a screwdriver.
- Short press the mechanical push-button 5 times in quick succession.

The status LED blinks green on the Puck.

**NOTE:** If the Puck is located behind the mechanical push-button, the status LED is not visible.




The load (light) connected to the Puck blinks for a few times. The status LED stops blinking green on the Wireless switch and the Puck. The Puck can now be controlled by the Wireless switch.

## Pairing Wireless switch with Micro module shades control (Puck)

 Short press the upper push-button 5 times in quick succession on the Wireless switch.

The status LED blinks green.

**NOTE:** The pairing mode will be active for about a minute.



2.

### WARNING

#### HAZARD OF ELECTRIC SHOCK

- Observe the regulations for working on live parts.
- Only actuate the device buttons using insulated auxiliary equipment that meets the requirements of EN 60900.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow either of the options to pair Puck:

- Short press the Setup/Reset button 5 times in quick succession on the Puck with a screwdriver.
- Short press the mechanical double push-button 1 for 5 times in quick succession.

The status LED blinks green on the Puck.

**NOTE:** If the Puck is located behind the mechanical double push-button, the status LED is not visible.




The shutter will move up and down a few times. The status LED stops blinking green on the Wireless switch and the Puck. The Puck can now be controlled by the Wireless switch.

# **Using the Wireless switch in Quick Home Connect**

## **Operating a dimmer**


You can switch the dimmer on/off or adjust its brightness using the paired Wireless switch.

 Short press the top or bottom Wireless switch (< 0,5 s) to turn on or off the connected load (A). • Long press the top or bottom Wireless switch (> 0,5 s) to increase or decrease the brightness of the connected load (B).



### Operating a relay

You can turn the light On/Off using the paired Wireless switch. Short press the top or bottom Wireless switch (< 0,5 s) to turn On or Off the light.




### Operating a shades control

You can operate the shades control using the Wireless switch.


Long press the Wireless switch (> 0,5 s) to move the shades control up or down.

- · Press to open the shades control (A)
- Press to close the shades control (B)



Short press top or bottom Wireless switch (< 0.5 s) to stop the moving shades control (C).

Short press top or bottom Wireless switch (< 0,5 s) to adjust the slat position (D).



## **Resetting the device in Quick Home Connect**

It is necessary to reset the devices in the following scenarios:

- · Unpair the device in Quick Home Connect:
  - Refer to Resetting the Wireless switch, Micro module light switch, Micro module shades control, Multiwire micro module dimmer.

When reset is done successfully. The Wireless switch and device returns to factory default.

- Integrating into Wiser System
  - If you wish to integrate the devices into Wiser System, reset all the devices in Quick Home Connect and refer to Pairing the device with Wiser Hub, page 14.

### **LED indications in Quick Home Connect**

#### Pairing the device in Quick Home Connect

| User Action  | LED Indication                     | Status  |
|--|------------------------------------|---|
| Press the push button 5 times in quick succession. | LED blinks green, once per second. | Pairing mode is active for 60 seconds. When pairing is completed, LED stops blinking. |

# **Troubleshooting in Quick Home Connect**

| Symptom   | Possible cause Solution  |   |  |
|---|--|---|--|
| LED displays amber in Puck (Micro module light switch or Micro module shades control or Multiwire micro module dimmer). | Pairing not completed and returned to factory reset.                 | Pair the Wireless switch and the device again. Refer to Pairing Wireless switch with Micro module light switch, page 10, Pairing Wireless switch with Micro module shades control, page 11, Pairing Wireless switch with Multiwire micro module dimmer, page 9. |  |
|   | The Wireless switch and the device are too far away from each other. | Place the Wireless switch in a position closer to the device.   |  |
| Wireless switch not able to control the device reliably.  | The Wireless switch lost pairing.                                    | Pair the device again  Refer to Pairing Wireless switch with Micro module light switch, page 10, Pairing Wireless switch with Micro module shades control, page 11, Pairing Wireless switch with Multiwire micro module dimmer, page 9.                         |  |
|   | The Wireless switch battery is discharged.                           | Replace the battery of the Wireless switch.   |  |

| Scenario   | Procedure  |
|--|--|
| Control multiple devices with one Wireless switch. | To centralize control with one Wireless switch, first pair it with already connected devices. Then, pair the new device to existing group/network. |

# Pairing the device

Using the Wiser Home app, pair your Wireless switch with the **Wiser Hub** to access and control the Wireless switch.

**NOTE:** You can change the Wireless switch from 1-gang to 2-gang using the app during commissioning. If the Wireless switch is already configured to 1-gang and you want to change it to 2-gang, then reset the device (1-gang), refer to Resetting the device, page 19 and commission it again with 2-gang.

Follow the steps below to pair the Wireless switch:


- 1. On the Home page, tap
- Tap Devices > and tap Appliances (tab) > Connected Wireless Switch > Next.

**TIP:** The next screen shows the joining process of the **Connected Wireless Switch**.


3. On the 2-gang Connected Wireless Switch, press the top-right push button fast three times.

**TIP:** Incase of 1-gang Connected Wireless Switch, press the top-center push button fast three times.

Make sure the LED blinks amber.



Wait for a few seconds until the LED turns green. You can also see in the app that the 2-gang Connected Wireless Switch is joined.



4. Tap **Next** to enter 2-gang Connected Wireless Switch name and assign it to an existing room or a new room.


You can see the added 2-gang Connected Wireless Switch on the Home page under the room tab or under **ALL** devices.

# Configuring the device

## **Setting the device location**

You can change the device location using Wiser Home app (such as bedroom, living room, dining room etc.).

- 1. On the Home page, tap 🖏
- Tap **Devices**, select the device from the list for which you wish to change the location.
- 3. Tap **Location** to open setup page.
- 4. On setup page, you can enter **New room name** (A) or select an existing room from the list (B).



**TIP:** If the device is already assigned, you can remove it from the existing room. Tap **Remove from Room** (C).


5. Once changes are done, tap Submit (D).

# Renaming the device

Using the Wiser Home app, you can rename your Wireless switch. Follow the step to rename the Wireless switch:

1. On the Home page, tap

2. Tap **Devices > 2-gang Connected Wireless Switch > Device Name** (A) to rename the Wireless switch.



# Identifying the device

Using the Wiser Home app, you can identify a Wireless switch from the other available devices in the room.

Follow the steps below to identify the Wireless switch:

1. Press 3 times on all the Wireless switch available in the room.

**TIP:** Pressing 3 times on the Wireless switch, it wakes up for 1 minute.

The Wireless switch LED blinks green 5 times and then stops.

2. Tap Devices > 2-gang Connected Wireless Switch > Identify (A) in the app.

#### NOTE:

- This feature flashes the Wireless switch LEDs, so you can identify the actual device. It may take up to a minute to start and flash the Wireless switch LED.
- The Wireless switch LED will continue to flash until you tap OK.
- 3. Check which Wireless switch LED starts blinking green.



# Removing the device from the system

Using the Wiser Home app, you can remove the Wireless switch from the Wiser system.

Follow the step to remove the Wireless switch:

- 1. On the Home page, tap 🐯.
- 2. Tap **Devices > 2-gang Connected Wireless Switch > Delete** (A) and short press the top-right push button 3 times on the **Wireless switch** to activate the device.



**NOTE:** By removing the device, you will reset the device. If you still have a problem with the reset, then refer to reset the device, page 19.

### Resetting the device

You can reset the Wireless switch to factory default manually. It can be reset manually at any time, e.g., when the Hub is replaced or when you are Changing Wireless switch from 1-gang to 2-gang, page 7 or vice versa. Follow the steps below to reset the Wireless switch:


1. Short press the top-right push button three times (< 0.5 s) and then press and hold the push button (>10 s).

**TIP:** In case of the 1-gang Wireless switch, short-press the top-center push button three times (< 0.5 s) and then press and hold the push button (>10 s).

- 2. After 10 s, the LED starts blinking red, then release the push button. The LED stops blinking upon successful reset of the device.
- 3. The Wireless switch restarts and blinks green for a few seconds.

#### NOTE:

- · After reset, the LED turns off to save the battery.
- All configuration data, user data, and network data are deleted.



# Using the device

### **Switching operation**

You can operate Wireless switch by pressing the push button manually.



#### Light

Short press on the upper/lower part of the push button for switching on or off, long press for dimming up or down.

#### Shutter

Long press on the upper/lower part of the push button to drive the shutter up or down.

#### Moment

Short press the push button to activate a Moment.


**TIP:** You can configure Wireless switch push button with Action/Moment using the app.

# **Assigning an Action to a Push Button**

Using the Wiser Home app, you can configure an "Action" to the Wireless switch push button (such as switching light On/Off, shutter up or down).

Follow the steps below to configure an Action to the Wireless switch push button:


- 1. On the Home page, tap the Wireless switch under **All** devices or under the room (tab) where it is located.
- 2. Tap any below listed switch to configure and select Action .





Select the device which you want to add as an Action.
 For example, the **Top Left** switch push button is configured with Action: Light Switch On.


4. On the **Select device** page, select the **Light Switch** and tap **Select Action**.



5. Tap to turn On the light and tap **Set > Set Action**.



**TIP:** In the next screen,  $\checkmark$  shows the Action is successfully configured. You can see the Top Left switch push button is configured with Light Switch: On.




# **Assigning a Moment to the Push Button**

Using the Wiser Home app, you can configure a Moment to the Wireless switch push buttons (such as Good Night Moment: Fan on, light dimming 50%, shutter close).

Follow the steps below to configure a Moment to the Wireless switch push button:

- 1. On the Home page, tap the Wireless switch under **All** devices or under the room (tab) where it is located.
- 2. Tap any below listed switch and select Moment.





Select a Moment which you want to add to the push button and tap Select Moment.

TIP: In the next screen, ✓ shows the Moment is successfully configured. For example, the **Top Left switch** is configured with Moment: Movie Night.



# **Removing configured Action/Moment**

Using the Wiser Home app, you can remove the existing configured Action or Moment from the Wireless switch push-button.

Follow the steps below to remove the configured Action/Moment:

- 1. On the Home page, tap the Wireless switch under **All** devices or under the room (tab) where it is located.
- 2. Tap push button and tap **Action / Moment >Remove > Yes I'm confirm** to remove configured Action/Moment from the Wireless switch push button.



# Replacing the battery

Replace the device battery when the level is low or critically low. The battery level can be seen in the app.

Follow the steps to replace the battery from the device:

### **AWARNING**

#### **CHEMICAL BURN HAZARD**

Keep batteries out of reach of children. If swallowed, seek immediate medical attention.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

### NOTICE

#### **EQUIPMENT DAMAGE**


The device is locked on the fixing plate with retaining claws. Never pull the device before sliding it upwards.

Failure to follow these instructions can result in equipment damage.

- 1. Remove the device from the fixing plate by sliding it upwards.
- 2. Rotate the device by 180° to access the battery cover.
- 3. Press and hold the battery cover with your thumb.
- 4. Slide the battery cover with another thumb to remove.
- Remove the old battery and press any push button on the device for a few seconds.

**NOTE:** Dispose the used batteries, as per statutory regulations.

- 6. Insert the battery with plus (+) symbol facing outward
- 7. Secure the battery cover.



# **LED** indications

#### Pairing the device

| User Action                             | LED Indication                      | Status  |
|---|-------------------------------------|---|
| Press the top right push button 3 times | LED blinks orange, once per second. | Pairing mode is active for 30 seconds. When pairing is completed, LED displays solid green for a few seconds, before turning Off. |

#### Resetting the device

| User Action   | LED Indication                   | Status   |
|---|----------------------------------|--|
| Press the push button 3 times and hold it down once for > 10 s. | LED blinks red, once per second. | The device is in reset mode. The device then restarts and the LED starts blinking green, before turning Off. |
|   |                                  |  |

#### **Battery level**

| LED Indication                                      | Status  |
|---|---|
| LED blinks red once, when a push button is pressed. | The battery is low (< 10%), Replace the Wireless switch battery, page 24. |
|   | NOTE: A notification pop-up will appear on the app.                       |

# **Troubleshooting**

| Symptom  | Possible cause                                 | Solution  |  |
|--|--|---|--|
| LED blinks red                                   | The Wireless switch battery is low or          | Replace the Wireless switch battery, page 24.                             |  |
| LLD DIIINS TEG.                                  | drained.                                       | <b>NOTE:</b> A notification pop–up will appear on the app.                |  |
|  | The Wireless switch battery is low or drained. | Replace the Wireless switch battery, page 24.                             |  |
| The Wireless switch displays offline in the app. | The Wireless switch is disconnected from       | Press any push button on the Wireless switch.                             |  |
|  | the network.                                   | <b>NOTE</b> : The first press does not trigger Wireless switch operation. |  |

# **Technical Data**

| Battery                                | CR2032   |
|--|--|
| Battery life                           | Up to 5 years (depending on frequency of use and quality of battery) |
| IP rating                              | IP20   |
| Operating frequency                    | 2405-2480 MHz  |
| Max. radio-frequency power transmitted | <10 mW   |
| Range                                  | 100 m open space   |
| Operating temperature                  | -5 °C to 45 °C   |
| Relative humidity                      | 5% to 95%  |
| Communication protocol                 | Zigbee 3.0   |

# **Compliance**

# **Compliance information for Green Premium products**

Find and download comprehensive information about Green Premium products, including RoHS compliance and REACH declarations as well as Product Environmental Profile (PEP) and End-of-Life instructions (EOLI).

https://checkaproduct.se.com/



### **General information about Green Premium products**

Click the link below to read about Schneider Electric's Green Premium product strategy.

https://www.schneider-electric.com/en/work/support/green-premium/



### **Trademarks**

This guide makes reference to system and brand names that are trademarks of their relevant owners.

- Zigbee® is a registered trademark of the Connectivity Standards Alliance.
- Apple® and App Store® are brand names or registered trademarks of Apple Inc.
- Google Play™ Store and Android™ are brand names or registered trademarks of Google Inc.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- Wiser™ is a trademark and the property of Schneider Electric, its subsidiaries and affiliated companies.
- Amazon Alexa™ is a trademark of AMAZON TECHNOLOGIES, INC.
- Google Home™ is a trademark of Google INC.

Other brands and registered trademarks are the property of their respective owners.

Schneider Electric 35 rue Joseph Monier 92500 Rueil Malmaison France

+ 33 (0) 1 41 29 70 00

www.se.com

As standards, specifications, and design change from time to time, please ask for confirmation of the information given in this publication.

© 2021 – 2024 Schneider Electric. All rights reserved.

DUG\_System M and System D - Wireless Switch\_WH-04