Modicon X80 BMXEAE0300 SSI Module User Manual

Original instructions

09/2020



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2020 Schneider Electric. All rights reserved.

Table of Contents



	Safety Information
	About the Book
Part I	BMX EAE 0300 Overview
Chapter 1	Module Introduction
•	General Information about SSI Functions
	General Information about the SSI Module BMX EAE 0300
	Physical Description of the SSI Module BMX EAE 0300
	Dimensions of X80 BMXEAE0300(H) SSI Module
	Characteristics of the SSI Module BMX EAE 0300
	Standards and Certifications
Chapter 2	SSI Module Installation
•	Mounting the SSI Module BMX EAE 0300
	Mounting the BMX FTB 2800/2820 Terminal Block
	How to Avoid Electromagnetic Interference
	Shielding Connection Kit
	LED Indicators
Chapter 3	Inputs/Outputs Specifications
	Capture Digital Input Characteristics
	Reflex Digital Output Characteristics
	Programmable Input Filtering
Part II	SSI Module BMX EAE 0300 Functionalities 4
Chapter 4	Configuration parameters 4
	Configuration Screen for the SSI Module BMX EAE 0300
Chapter 5	SSI Module BMX EAE 0300 Functions 4
	SSI Interface
	Modulo and Reduction Functions
	Offset Function 5
	Inverted SSI Direction Function
	Multiple Application of Reformatting
	Capture Function
	Compare Function
	SSI Status Register
	Event Sent To Application 6
	Output Block Functions

Chapter 6	Adjustment
-	Screen for the SSI Module BMX EAE 0300
Chapter 7	Debugging the SSI Module BMX EAE 0300
•	Debug Screen for the SSI Module BMX EAE 0300
Chapter 8	Diagnostic of the SSI Module BMX EAE 0300
	Diagnostic Screen for the SSI Module BMX EAE 0300
Chapter 9	The Language Objects of the SSI Function
9.1	The Language Objects and IODDT of the SSI Function
	Introducing Language Objects for Application-Specific SSI
	Implicit Exchange Language Objects Associated with the Application-
	Specific Function
	Explicit Exchange Language Objects Associated with the Application-Specific Functions
	Management of Exchanges and Reports with Explicit Objects
9.2	Language Objects and IODDTs Associated with the SSI Function
	General Information
	Details of the Language Objects of the IODDT of Type T_GEN_MOD
	Exchange Objects for the T_SSI_BMX IODDT
9.3	Language Objects and Device DDT Associated with the SSI Function
	Device DDT for BMX EAE 0300 Module
	MOD_FLT Byte Description
	DDT Description for Explicit Exchange
Part III	Quick Start: SSI Module BMX EAE 0300 Implemen-
	tation Example
Chapter 10	Example Overview
	Example Introduction
	Application Background
Chapter 11	Hardware Installation
	Mounting the Module and the Terminal Block
	Wiring Diagram of the Process
Chapter 12	Configuring the SSI Module BMX EAE 0300 on
•	Control Expert
	Configuration of the SSI Module BMX EAE 0300

Chapter 13	Programming the Example	113
-	Declaration of Variables	114
	Creating the Program	115
	Transferring the Project between the Terminal and the PLC	116
Chapter 14	Diagnostic and Debugging	119 119
Index		

Safety Information



Function Block Library and System User Guide Specific Safety Information

BEFORE YOU BEGIN

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

A WARNING

UNGUARDED EQUIPMENT

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

Only you, the user, machine builder or system integrator can be aware of all the conditions and factors present during setup, operation, and maintenance of the machine and, therefore, can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, you should refer to the applicable local and national standards and regulations. The National Safety Council's Accident Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch points or other hazardous areas and serious injury can occur. Software products alone cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the Function Block Library, System User Guide, or other implementation referenced in this documentation.

START-UP AND TEST

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

A WARNING

EQUIPMENT OPERATION HAZARD

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and temporary grounds that are not installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment.
- Close the equipment enclosure door.
- Remove all temporary grounds from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

OPERATION AND ADJUSTMENTS

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection
 and ratings of components, there are hazards that can be encountered if such equipment is
 improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe
 operation. Always use the manufacturer's instructions as a guide for functional adjustments.
 Personnel who have access to these adjustments should be familiar with the equipment
 manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.



WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result** in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book



At a Glance

Document Scope

This manual describes the hardware and software implementation of SSI (Synchronous Serial Interface) module BMXEAE0300.

Validity Note

This documentation is valid for EcoStruxure™ Control Expert 15.0 or later.

The technical characteristics of the devices described in the present document also appear online. To access the information online:

Step	Action
1	Go to the Schneider Electric home page <u>www.schneider-electric.com</u> .
2	 In the Search box type the reference of a product or the name of a product range. Do not include blank spaces in the reference or product range. To get information on grouping similar modules, use asterisks (*).
3	If you entered a reference, go to the Product Datasheets search results and click on the reference that interests you. If you entered the name of a product range, go to the Product Ranges search results and click on the product range that interests you.
4	If more than one reference appears in the Products search results, click on the reference that interests you.
5	Depending on the size of your screen, you may need to scroll down to see the datasheet.
6	To save or print a datasheet as a .pdf file, click Download XXX product datasheet .

The characteristics that are described in the present document should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the document and online information, use the online information as your reference.

Related Documents

Title of documentation	Reference number
Modicon M580, M340, and X80 I/O Platforms, Standards and Certifications	EIO000002726 (English), EIO0000002727 (French), EIO0000002728 (German), EIO000002730 (Italian), EIO0000002729 (Spanish), EIO0000002731 (Chinese)
EcoStruxure™ Control Expert, Operating Modes	33003101 (English), 33003102 (French), 33003103 (German), 33003104 (Spanish), 33003696 (Italian), 33003697 (Chinese)
EcoStruxure™ Control Expert, Communication, Block Library	33002527 (English), 33002528 (French), 33002529 (German), 33003682 (Italian), 33002530 (Spanish), 33003683 (Chinese)
EcoStruxure™ Control Expert, I/O Management, Block Library	33002531 (English), 33002532 (French), 33002533 (German), 33003684 (Italian), 33002534 (Spanish), 33003685 (Chinese)

You can download these technical publications and other technical information from our website at www.schneider-electric.com/en/download.

Product Related Information



UNINTENDED EQUIPMENT OPERATION

The application of this product requires expertise in the design and programming of control systems. Only persons with such expertise should be allowed to program, install, alter, and apply this product.

Follow all local and national safety codes and standards.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Part I BMX EAE 0300 Overview

Overview

This part gives an overview of the SSI module BMX EAE 0300 and its technical specifications.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	Module Introduction	15
2	SSI Module Installation	23
3	Inputs/Outputs Specifications	37

Chapter 1 Module Introduction

Overview

This chapter gives an overview of the SSI module.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
General Information about SSI Functions	16
General Information about the SSI Module BMX EAE 0300	17
Physical Description of the SSI Module BMX EAE 0300	18
Dimensions of X80 BMXEAE0300(H) SSI Module	19
Characteristics of the SSI Module BMX EAE 0300	20
Standards and Certifications	22

General Information about SSI Functions

Overview Description

The module BMX EAE 0300 is a synchronous serial interface designed for use with an absolute encoder, it is controlled by the user applications through an open SSI interface.

The position values of the SSI channel are automatically read by the module every fixed period, unless the channel is disabled.

Available Functions

The following table presents the main functionalities of the BMX EAE 0300 module:

Function	Description
Modulo	The modulo function limits the dynamics of the position value within the power of 2. An event (if enabled) detects the modulo passing. The reflex output can also be asserted at the passing of modulo (if configured).
Reduction	This function reduces the intrinsic resolution of the encoder by a value defined by the "reduction" parameter. This reduction is carried out by a shift in the bit field provided by the encoder.
Offset	The correction function of the encoder offset systematically corrects the offset produced by the encoder at mechanical position "0". The user enters the absolute encoder offset parameter.
Capture	The two capture input registers (per channel) enable the PLC program to carry out a dynamic measurement function between two points. The capture action can be triggered by two capture inputs. The event will be triggered at each occurrence of Capture.
Compare	Two independent comparators (per channel), with thresholds that can be modified by adjustment (explicit exchange), are able to generate an event or reflex output when the threshold is crossed.

General Information about the SSI Module BMX EAE 0300

Definition


The SSI module BMX EAE 0300 is a 3-channel, synchronous serial interface, absolute encoder interface.

It supports:

- 3 channels of SSI inputs
- 1 reflex output for each SSI channel
- 2 capture inputs for the 3 SSI channels
- 8 to 31 bits data width
- 4 ranks of baud rates (100 kHz, 200 kHz, 500 kHz, 1 MHz)
- capture and compare functions

Illustration

The illustration below shows the basic components of an absolute encoder system:




- 1 Absolute encoder
- 2 Proximity sensors
- 3 SSI module BMX EAE 0300

Physical Description of the SSI Module BMX EAE 0300

Illustration

The figure below presents the SSI module BMX EAE 0300:



- 1 BMX EAE 0300
- 2 28-pin removable terminal block

NOTE: The terminal block is supplied separately.


Required Accessories

The SSI module BMX EAE 0300 requires the use of the following accessories:

- 28-pin removable terminal block BMX FTB 2800/2820 (see page 26)
- One BMXXSP•••• shielding connection kit (see page 32)

Dimensions of X80 BMXEAE0300(H) SSI Module

General Presentation of X80 BMXEAE0300(H) SSI Module



a DIN-rail depth: the value depends on the DIN-rail type used in your platform.

Dimensions of X80 BMXEAE0300(H) SSI Module

Module reference	Module dimensions	Installation depth ⁽¹⁾		
	Width	Height	Depth	
BMXEAE0300(H)	32 mm (1.26 in.)	103.7 mm (4.08 in.)	86 mm (3.39 in.)	119.5 mm (4.69 in.) ⁽¹⁾
(1) DIN-rail depth (a) is not included.				

NOTE: Connectors that are delivered with BMXEAE0300(H) modules (28-pin removable terminal blocks) and the corresponding pre-assembled cordsets (BMXFTW*08S) have the same dimensions.

NOTE: Consider clearance for cable installation and spacing around the racks.

Characteristics of the SSI Module BMX EAE 0300

Ruggedized Version

The BMX EAE 0300H (hardened) equipment is the ruggedized version of the BMX EAE 0300 (standard) equipment. It can be used at extended temperatures and in harsh chemical environments.

For more information, refer to chapter *Installation in More Severe Environments (see Modicon M580, M340, and X80 I/O Platforms, Standards and Certifications).*

Altitude Operating Conditions

The characteristics in the table below apply to the modules BMX EAE 0300 and BMX EAE 0300H for use at altitude up to 2000 m (6560 ft). When the modules operate above 2000 m (6560 ft), apply additional derating.

For detailed information, refer to chapter *Operating and Storage Conditions* (see Modicon M580, M340, and X80 I/O Platforms, Standards and Certifications).

General Characteristics

This table presents the general characteristics of the SSI module BMX EAE 0300 and BMX EAE 0300H:

SSI Channels	Maximum SSI Baud Rate	100k, 200k, 500k, 1M	
	SSI Channel Number	3	
	Bit Width	8 to 31 bits	
	Refresh interval	= 1 ms	
Regular I/O Channels	Number of Digital Inputs	Two 24 Vdc Type 3 inputs per module	
	Number of Digital Outputs	One 24 Vdc output per channel	
Hot Swapping Supported		Yes	
Encoder Compliance		Absolute encoder 24 V model with standard SSI interface (tolerance: 19.2-30 Vdc)	
Power Supply to Encoder		Voltage: 24 Vdc (Supplied by the field power) Current: < 200 mA per channel (for 24 Vdc)	
Power Distribution To Encod	er	Yes, short circuit limited (700 mA total)	
Back Plane Power Consumption	+ 3.3 Vdc	Typical: 150 mA Maximum: 250 mA	
	+ 24 Vdc	Not used	
Dielectric Strength	Field To Bus	1400 Vdc for 1 minimum	
Field Power	Voltage	19.2 to 30 Vdc (24 Vdc typical) Over-voltage protected up to 45 Vdc.	
	Current	It depends on the encoder(s) and the load of reflex output consumption. For module operating: 30 mA.	
Operating temperature	BMX EAE 0300	060 °C (32140 °F)	
	BMX EAE 0300H	-2570 °C (-13158 °F)	

NOTE: The encoder is required to have at least 5 mA output current to activate the DATA input of the SSI module.

▲ WARNING

EQUIPMENT DAMAGE

Do not allow the supplied voltage to exceed the maximum allowed voltage of the encoder when the module BMX EAE 0300 or BMX EAE 0300H is used to provide power to encoder.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Standards and Certifications

Download

Click the link that corresponds to your preferred language to download standards and certifications (PDF format) that apply to the modules in this product line:

Title	Languages
Modicon M580, M340, and X80 I/O Platforms,	• English: <u>EI00000002726</u>
Standards and Certifications	 French: <u>EIO000002727</u> German: <u>EIO000002728</u>
	• Italian: <u><i>EIO0000002730</i></u>
	• Spanish: <u>E/O0000002729</u>
	• Chinese: <u>EIO0000002731</u>

Chapter 2 SSI Module Installation

Overview

This chapter provides information to install the module.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Mounting the SSI Module BMX EAE 0300	24
Mounting the BMX FTB 2800/2820 Terminal Block	26
How to Avoid Electromagnetic Interference	30
Shielding Connection Kit	32
LED Indicators	35

Mounting the SSI Module BMX EAE 0300

At a Glance

Handling the module while the power supply to the rack is turned on does not disturb the PLC.

Installation Precautions

The Modicon X80 SSI modules may be installed in any of the positions in the rack except:

- the positions reserved for the rack power supply modules (marked PS, PS1, and PS2),
- the positions reserved for extended modules (marked XBE),
- the positions reserved for the CPU in the main local rack (marked 00 or marked 00 and 01 depending on the CPU).
- the positions reserved for the (e)X80 adapter module in the main remote drop (marked 00).

Power is supplied by the bus at the bottom of the rack (3.3 V and 24 V).

Before installing a module, you must take off the protective cap from the module connector located on the rack.

A A DANGER


HAZARD OF ELECTRIC SHOCK

- Disconnect voltage supplying sensors and pre-actuators before plugging / unplugging the terminal block on the module.
- Remove the terminal block before plugging / unplugging the module on the rack.

Failure to follow these instructions will result in death or serious injury.

Installation

The diagram below shows SSI module BMX EAE 0300 mounted on the rack:



The following table describes the different elements which make up the assembly below:

Number	Description
1	SSI module BMX EAE 0300
2	Standard rack

Installing the Module on the Rack

The following table shows the procedure for mounting the SSI module in the rack:

Step	Action	Illustration
1	Position the locating pins situated at the rear of the module (on the bottom part) in the corresponding slots in the rack. NOTE: Before positioning the pins, make sure you have removed the protective cover from the rack slot.	Steps 1 and 2
2	Swivel the module towards the top of the rack so that the module sits flush with the back of the rack. It is now set in position.	
3	Tighten the mounting screw to ensure that the module is held in place on the rack. Tightening torque: 0.41.5 N•m (0.301.10 lbf-ft)	Step 3

Mounting the BMX FTB 2800/2820 Terminal Block

Terminal Block

SSI module BMX EAE 0300 requires the BMX FTB 2800/2820 28-pin terminal block to be inserted into the front of the module. These fitting operations (assembly and disassembly) are described below.

Cable Ends and Contacts

Each terminal block can accommodate:

- Bare wires
- · Wires with:
 - O DZ5-CE (ferrule) type cable ends:
 - o AZ5-DE (twin ferrule) type cable ends:

NOTE: When using stranded cable, Schneider Electric strongly recommends the use of wire ferrules which are fitted with an appropriate crimping tool.

Description of the 28-Pin Terminal Blocks

The following table describes the type of wires that fit each terminal block and the associated gauge range, wiring constraints, and tightening torque:

	Caged terminal blocks BMX FTB 2800	Spring terminal blocks BMX FTB 2820
Illustration		
1 solid conductor	• AWG: 2218 • mm ² : 0.341	• AWG: 2218 • mm ² : 0.341

	Caged terminal blocks BMX FTB 2800	Spring terminal blocks BMX FTB 2820
2 solid conductors	Only possible with twin ferrule: • AWG: 2 x 2420 • mm ² : 2 x 0.240.75	Only possible with twin ferrule: • AWG: 2 x 2420 • mm ² : 2 x 0.240.75
1 stranded cable	• AWG: 2218 • mm ² : 0.341	• AWG: 2218 • mm ² : 0.341
2 stranded cables	Only possible with twin ferrule: • AWG: 2 x 2420 • mm ² : 2 x 0.240.75	Only possible with twin ferrule: • AWG: 2 x 2420 • mm ² : 2 x 0.240.75
1 stranded cable with ferrule	• AWG: 2218 • mm ² : 0.341	• AWG: 2218 • mm ² : 0.341
2 stranded cables with twin ferrule	 AWG: 2 x 2420 mm²: 2 x 0.240.75 	 AWG: 2 x 2420 mm²: 2 x 0.240.75
Minimum individual wire size in stranded cables when a ferrule is not used	• AWG: 30 • mm ² : 0.0507	• AWG: 30 • mm ² : 0.0507
Wiring constraints	Caged terminal blocks have slots that accept: Flat-tipped screwdrivers with a diameter of 3 mm. Caged terminal blocks have captive screws. On the supplied blocks, these screws are not tightened.	The wires are connected by pressing the button located next to each pin. To press the button, you have to use a flat-tipped screwdriver with a maximum diameter of 3 mm.
Screw tightening torque	0.4 N•m (0.30 lb-ft)	Not applicable

⚠ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK

Turn off all power to sensor and pre-actuator devices before connection or disconnection of the terminal block.

Failure to follow these instructions will result in death or serious injury.

Installing the 28-Pin Terminal Block

A CAUTION


TERMINAL BLOCK IMPROPERLY FIXED TO THE MODULE

Follow the procedure instructions to fix the terminal block to the module.

Verify that the screws are tightened.

Failure to follow these instructions can result in injury or equipment damage.

The following table shows the procedure for assembling the 28-pin terminal block onto an SSI module BMX EAE 0300:




Assembly procedure:

Step	Action
1	Once the module is in place on the rack, install the terminal block by inserting the terminal block encoder (the rear lower part of the terminal) into the module encoder (the front lower part of the module), as shown in previous illustration.
2	Fix the terminal block to the module by tightening the 2 mounting screws located on the lower and upper parts of the terminal block. Tightening torque: 0.4 N•m (0.29 lb•ft).

28 Pin Terminal Block Arrangements

The terminal block is arranged as followed:



How to Avoid Electromagnetic Interference

Overview

Electromagnetic perturbations may cause the application to operate in an unexpected manner.

A WARNING


UNEXPECTED EQUIPMENT OPERATION

In a highly disturbed electromagnetic environment,

- use the BMXXSP *** shielding connection kit (see page 32) to connect the shielding and
- use a stabilised 24 Vdc supply for inputs and a shielded cable for connecting the supply to the module.
- use a shielded cable for capture inputs and reflex outputs if any of them is wired.
- use a shielded cable for each SSI channel respectively and note that 24 Vdc and GND must be included in the shielded cable. (Each shielded cable includes CLK pair, DATA pair, 24Vdco, 0Vdco. If the reflex output is connected to encoder, it also has to be included.)

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The figure below shows the recommended circuit for a high-noise environment using the shielding connection kit:



A CAUTION

POTENTIAL MODULE DAMAGE - IMPROPER FUSE SELECTION

Use fast acting fuses to protect the electronic components of the module from overcurrent and reverse polarity of the input/output supplies. Improper fuse selection could result to damage to the module.

Failure to follow these instructions can result in injury or equipment damage.

Shielding Connection Kit

Introduction

The BMXXSP•••• shielding connection kit allows to connect the cable shielding directly to the ground and not to the module shielding to help protect the system from electromagnetic perturbations.

Connect the shielding on the cordsets for connecting:

- Analog module,
- Counter module,
- Encoder interface module,
- Motion control module,
- An XBT console to the processor (via shielded USB cable).

Kit References

Each shielding connection kit includes the following components:

- A metal bar
- Two sub-bases

The shielding connection kit reference is dependent on the size of the Modicon X80 rack::

X bus racks/Dual Ethernet and X bus racks	Number of slots	Shielding Connection Kit				
BMXXBP0400(H)	4	BMXXSP0400				
BMEXBP0400(H)	4	BIVIAASPU4UU				
BMXXBP0600(H)	6	BMXXSP0600				
BMXXBP0800(H)		DMAYYODOOO				
BMEXBP0800(H)	8	BMXXSP0800				
BMXXBP1200(H)	40	BMXXSP1200				
BMEXBP1200(H)	12					

Redundant power supply racks	Number of slots	Shielding Connection Kit
BMEXBP0602(H)	6	BMXXSP0800
BMEXBP1002(H)	10	BMXXSP1200

Clamping Rings

Use clamping rings to connect the shielding on cordsets to the metal bar of the kit.

NOTE: The clamping rings are not included in the shielding connection kit.


Depending on the cable diameter, the clamping rings are available under the following references:

- STBXSP3010: small rings for cables with cross-section 1.5...6 mm² (AWG16...10).
- STBXSP3020: large rings for cables with cross-section 5...11 mm² (AWG10...7).

Kit Installation

Installation of the shielding connection kit to the rack can be done with module already installed on the rack except for the BMXXBE0100 rack extender module.

Fasten the sub-bases of the kit at each end of the rack to provide a connection between the cable and the ground screw of the rack:



- 1 rack
- 2 sub-base
- 3 metallic bar
- 4 clamping ring


Tightening torques to install the shielding connection kit:

- For the screws fixing the sub-base to the Modicon X80 rack: Max. 0.5 N•m (0.37 lbf-ft)
- For the screws fixing the metallic bar to the sub-bases: Max. 0.75 N•m (0.55 lbf-ft)

NOTE: A shielding connection kit does not modify the volume required when installing and uninstalling modules.

Kit Dimensions

The following figure gives the dimensions (height and depth) of a Modicon X80 rack with its shielding connection kit:



NOTE: The overall width equals to the width of the Modicon X80 rack.

LED Indicators

At a Glance

The SSI module BMX EAE 0300 is equipped with LEDs that display the module's channels status and detected errors.

Display Panels

LED display:



The first row of LEDs indicates module information:

- LED RUN: Indicates the module's operational status
- LED ERR: indicates an internal detected fault in the module or a detected fault between the module and the rest of the configuration
- LED I/O: Indicates an external detected fault
- LED DL: Indicates the Firmware download status

The second row of LEDs corresponds to SSI channels.

The LEDs are represented in the following way: (y = 0, 1 or 2 depending on the SSI channel)

- LED Sy: Channel y Input
- LED Qy: Reflex Output for channel y
- LED I0/1: Capture Input for 3 SSI channels

When a voltage is present on an input or output, the corresponding LED is lit.

Diagnostics

The following table allows you to perform diagnostics of the module status according to the LEDs: RUN, ERR, I/O, DL and channels (LEDs S0 to I1):

Module status	LED indicators											
	RUN	ERR	I/O	DL	S0	S1	S2	Q0	Q1	Q2	10	11
The module is not receiving power or has inoperative	0											
The module is inoperative	0	•	\circ	_	_	-	_	_	_	_	_	_
The module is not configured or is configuring its channels	0	\otimes	-	0	0	0	0	0	0	0	0	0

Module status	LED indicators											
	RUN	ERR	I/O	DL	S0	S1	S2	Q0	Q1	Q2	10	l1
Module has Lost communication with CPU	•	\otimes	-	0	-	-	-	-	-	-	-	-
Field Power Supply inoperative	•	0	•	0	\otimes	\otimes	\otimes	\otimes	\otimes	\otimes	\otimes	\otimes
Downloading firmware	\otimes	0	0	\otimes	-	-	-	-	-	-	-	-
S0 has a detected line error	•	0	•	0		-	-	-	-	-	-	-
S1 has a detected line error	•	0	•	0	-	\Diamond	-	-	-	-	-	-
S2 has a detected line error	•	0	•	0	-	-	0	-	-	-	-	-
Qx has a short circuit	•	0	•	0	-	-	-	\Diamond	\Diamond	0	-	-
Channels are operational	•	0	0	0	-	-	-	-	-	-	-	-
"Absolute SSI Encoder" mode is selected and no error	•	0	0	0	•	-	-	-	-	-	-	-
detected	•	0	0	0	-	•	-	-	-	-	-	-
	•	0	0	0	-	-	•	-	-	-	-	-
Voltage is present on Q0	•	0	0	0	-	-	-	•	-	-	-	-
Voltage is present on Q1	•	0	0	0	-	-	-	-	•	-	-	-
Voltage is present on Q2	•	0	0	0	-	-	-	-	-	•	-	-
Voltage is present on I0	•	\circ	0	0	-	-	-	-	-	-	•	-
Voltage is present on I1	•	0	0	0	-	-	-	-	-	-	-	•

LED on

 $\bigcirc_{\,\mathsf{LED}\,\mathsf{off}}$

LED flashing fast

An empty cell indicates that the state of the LED(s) is not taken into account

Chapter 3

Inputs/Outputs Specifications

Overview

This chapter contains information about the inputs and outputs of the SSI module.

NOTE: The SSI performances described in this chapter are only valid with wired as indicated in this documentation.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Capture Digital Input Characteristics	38
Reflex Digital Output Characteristics	39
Programmable Input Filtering	41

Capture Digital Input Characteristics

Capture Digital Input Characteristics

The table below describes the SSI module BMX EAE 0300 capture digital input characteristics:

Number of Input Channels		Two 24 Vdc inputs per module
IEC Type		IEC type 3
Digital Inputs:	Maximum Input Voltage	30 Vdc
CAP_IN0 CAP_IN1	ON Input Voltage	+11 +30 Vdc
CAF_INT	OFF Input Voltage	< 5 Vdc
	OFF Input Current	< 1.5 mA
	Nominal Input Current	(at < 30 Vdc) 5 mA
	Current at 11 Vdc	> 2 mA
	Over Voltage Protection	Maximum: 52 Vdc
	Reverse Polarity Protection	Maximum: 28 Vdc
Input Response Time		Refer to the input filter and bounce filter tables (see page 41)
Capture Response Time		<= 1 ms

Reflex Digital Output Characteristics

Reflex Digital Output Characteristics

The table below describes SSI module BMX EAE 0300 reflex digital output characteristics:

Number of outputs channels		One 24 Vdc 0.5 A per SSI channel, three channels per module		
Output Voltage		19.230 Vdc (depends on field supply)		
Output Type		Push-pull		
Maximum Load Current	Each Point	0.5 A		
	Per Module	1.5 A		
Leakage / point		-0.3 mA maximum (OFF)		
On State Output Voltage Drop		1.35 Vdc maximum (0.5 A)		
Maximum Load Capacitance		50 μF		
Maximum Load Inductance L = load inductance (Henry) I = load current (A) F = switching frequency (Hz)		0.5 Henry at 4 Hz switch frequency L = 0.5 / (I² x F)		
Maximum Physical Response Tim	ne	< 20 µs (Resistive load)		
Response Time for Comparison		<= 1ms		
Short Circuit		All channels are protected against short circuit and over temperature		
Fallback States	By default	Pre-defined fallback values on all channels		
(Output Channels)	User -Configurable Setting	Hold last value		
		Pre-defined fallback value on one or all channels		
Pre-defined Values	By default	Channels set to 0		
(Output Fallback)	User -Configurable Setting	Each channel configurable for 1 or 0		
Polarity On Individual Output	By default	Logic normal on all channels		
Channels	User -Configurable Setting	Logic reverse on one or all channels		
		Logic normal on one or all channels		

A WARNING

OUTPUT SHORT-CIRCUIT OR OVERLOAD

Do not apply a high voltage (24 Vdc) to an output port when it is at "0" because there is no internal short circuit protection.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTE:


If the short circuit occurs on any channel, the power supply goes into the following mode:

- Firstly the power supply cycles on as the hiccup mode, the peak current is less than 10 A with about a 2 µs duration.
- Then all channels are turned off after about 100 ms

Programmable Input Filtering

Overivew


Each of the SSI module BMX EAE 0300 inputs allows input filtering. There are four levels of filtering available (low, medium, high and without), that can be configured in the configuration screen, as shown:



Description

The filtering used is a programmable bounce filter, which operates as follows:

Bounce rejection diagram



In bounce rejection mode, the system delays all transitions until the signal remains stable for the duration defined for the filter level.

Bounce rejection levels:

Input	Filter Level	Min Pulse	Max Frequency
	Without	20 µs	200 Hz
CAP_IN0,1	Low (For Bounces > 2 kHz)	500 μs	200 Hz
	Medium (For Bounces > 1 kHz)	1.25 ms	200 Hz
	High (For Bounces > 250 Hz)	4.2 ms	100 Hz

Part II

SSI Module BMX EAE 0300 Functionalities

Subject of this Part

This part presents the functionalities of the SSI module BMX EAE 0300.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name				
4	Configuration parameters	45			
5	SSI Module BMX EAE 0300 Functions	47			
6	Adjustment 65				
7	Debugging the SSI Module BMX EAE 0300 69				
8	Diagnostic of the SSI Module BMX EAE 0300 71				
9	The Language Objects of the SSI Function 73				

Chapter 4

Configuration parameters


Configuration Screen for the SSI Module BMX EAE 0300

At a Glance

This section presents the configuration screen for the SSI module BMX EAE 0300.

Illustration

The figure below presents the configuration screen for the SSI module BMX EAE 0300:



Description of the Screen

The following table presents the various parts of the above screen:

Number	Column	Function
1	Tab	The tab in the foreground indicates the current mode. The current mode is the configuration mode in this example.
2	Label	These fields contain the name of each variable that may be configured. They may not be modified.
3	Symbol	These fields contain the address of the variable in the application. They may not be modified.
4	Value	If these fields have a downward pointing arrow, you can select the value of each variable from various possible values in these fields. The various values can be accessed by clicking on the arrow. A drop-down menu containing all the possible values is displayed and the user may then select the required value of the variable.
5	Unit	These fields contain the unit of each variable that may be configured. They may not be modified.

NOTE: Refer to the desired function *(see page 47)* in order to properly configure the SSI module BMX EAE 0300.

Chapter 5 SSI Module BMX EAE 0300 Functions

Overview

This chapter deals with functions of the SSI module BMX EAE 0300.

What Is in This Chapter?


This chapter contains the following topics:

Topic	Page
SSI Interface	48
Modulo and Reduction Functions	49
Offset Function	50
Inverted SSI Direction Function	51
Multiple Application of Reformatting	52
Capture Function	53
Compare Function	56
SSI Status Register	59
Event Sent To Application	60
Output Block Functions	62

SSI Interface

Description of the SSI Interface

The figure below represents a SSI frame:



NOTE: This module does not control the turn value. For multi-turn encoders, the angle and turn values constitute a single and unique value for the module.

The following are the other main characteristics of the frame and the interface:

Parameters	Values or observations
Code	Binary or Gray
SSI transmission baud rate	100 kHz, 200 kHz, 500 kHz or 1 MHz
Data bits	8 to 31 bits (MSB transferred first)
Status bits	0 to 1 bit (error bit may be handled by firmware)
Parity	Even, Odd or Without parity
Reloading Time	10 to 40 µs depending on encoder

Parameter Details

There are four choices for the baud rate parameter which impact the maximum cable length:

Baud rate	100 kHz	200 kHz	500 kHz	1 MHz
Maximum cable length	350 m	180 m	70 m	20 m

The **data bits** parameter enables the number of data bits supplied by the encoder to be declared (from MSB to LSB). The upper limit is 31.

The **Status bit** is the status flag which is refreshed when receiving this bit in the sequence. For some encorders, this bit can indicate the detected error in the data frame.

The **Parity** parameter enables a **Parity bit** to be declared in the frame. If the parity bit is selected, the modules carry out the parity check according to the choice of parity type, even or odd.

After the last rising edge of the clock signal, the **Reloading time** defines how long it takes until the rotary encoder can be selected for the next transmission. This reloading time is determined by the period of SSI pulse train. The reading cycle of SSI module is fixed by 1 ms.

Modulo and Reduction Functions

Description

The two functions are:

- Modulo: the modulo function limits the dynamics of the position value to within a number of
 points defined by the value of the parameter. An event (if enabled) detects the modulo (positive
 or negative) passing.
- Reduction: the function reduces the intrinsic resolution of the encoder by a value defined by the
 "reduction" parameter. This reduction is carried out by a shift in the bits field provided by the
 encoder.

The two parameters are of a "constant configuration" (%K) type.

Details for Modulo and Reduction

- The modulo and reduction value is expressed as the exponent of 2.
- The number of modulo bits is limited from 8 to 31 while the number of reduction bits is limited from 0 to 7 bit.
- When the reflex output is asserted ("1") by the presence of modulo value passing, it will keep
 the value "1" until a rising edge of an extra clear bit of %Q occurs.

The modulo passing detection is only available when module < data width.

For example: if the data width is 13-bit, then the modulo passing will not be detected when the modulo is from 13 to 31. (The default value of modulo is 31.)

Offset Function

Description

NOTE: The Encoder offset parameters are set in the Adjust tab.

Encoder offset: the user enters the absolute encoder offset parameter. The correction function of the encoder offset systematically corrects the offset produced by the encoder on mechanical position "0". This value is set in an adjustment word (%MW).

Inverted SSI Direction Function

Description

If the direction of input SSI data is inverted by the configuration, the output data is transferred by the following equation:

Inverted_value = 2^N - Original_value

N: encoder data width.

NOTE: Inverted_0 = 0.

Multiple Application of Reformatting

Description

In case the user applies all the reformatting function at the same time, it is necessary to define the priority of them: Invert > Reduction > Offset > Modulo.

Example

With the following conditions:

Data width = 11 bits

Modulo = 256 (8 bits)

Reduction = 1 bit

Enter the offset value after reduction.

In this example, because the full range resolution becomes 2^{11-1} after reduction, to have a physical offset of half range, the offset value should be set as:

Offset = 512

After the offset value has been added, if the reformatted value exceeds 2¹¹⁻¹, then the value will be masked by 2¹¹⁻¹.

If the original data is 00001001001 in binary (73 in decimal), while SSI direction is inverted:

Invert [73] = 2¹¹ - 73 = 1975

Reduct [1975] = 1975 / 21 = 987

Offset [987] = $987 + 512 - 2^{11-1} = 475$

Mod [475/256] = 219

The final result in %IW is 219. As to the Gray code, it will be converted by XCEL automatically. The original data in SSI register is always in binary.

Capture Function

Description


Capture is used to copy the current value of the SSI register to a capture register. It fixes the immediate value at the precise moment the operation started.

The SSI module has two capture inputs, CAP_IN0 and CAP_IN1 respectively.

The **Capture done** information is an event which can undergo an event processing operation.


Function Hardware Structure

The figure below shows the hardware structure of the capture function:



Operation

The trend diagram below shows the capture mode on the rising edge of CAP_IN:



The other mode (capture on falling edge) is similar.

Details of Capture Function

- The operation is triggered by the hardware when a CAP_IN physical input status is changed when the capture enabling command is enabled. The SSi module capture modes are:
 - Capture on rising edge of an CAP_IN input.
 The capture value is recorded in the Capture Register 0 for CAP_IN0, and in the Capture Register 1 for CAP_IN1.
 - Capture on falling edge of an CAP_IN input.
 The capture value is recorded in the Capture Register 0 for CAP_IN0, and in Capture Register 1 for CAP_IN1.
- If the Modulo (see page 49), Reduction (see page 49), Offset (see page 50) and SSI direction (see page 51) functions have been applied, the captured value is affected as well.
- The current value of SSI register must be valid before the event. If the Validity bit is false (low) the capture is not performed.
- The three SSI channels share the common capture inputs of CAP_IN0 and CAP_IN1. The capture action of unwanted channel(s) can be disabled by the validate bit.

Example Capture on Rising or Falling Edge

The capture mode on the rising or falling edge of a physical input can be used to monitor the progress of the manufacture of a part. This means that the position of the encoder can be captured when part enters.

Compare Function

Description

The comparison function allows triggering event tasks or a reflex output according to the current value in comparison to a threshold. The SSI module has two comparators. The comparison is made in both directions (upper threshold and lower threshold).

Example with Compare

These comparators can be used to warn that a position has been exceeded. As soon as the current value reaches the threshold, the event task associated with the module is called and can activate an alarm to inform you of the end of a maneuver.

Comparison Thresholds

The comparison block has two thresholds:

- The upper threshold: upper th value double word (%QDr.m.c.6)
- The lower threshold: lower th value double word (%QDr.m.c.4)

The upper threshold value must be greater than or equal to the lower threshold value.

If the upper threshold is less than the lower threshold, the threshold error bit (%IWr.m.c.1 x9) is asserted and all the compare functions of this channel are disabled.

The default value of upper_th_value and lower_th_value is 0.

A WARNING

UNEXPECTED REFLEX OUTPUT BEHAVIOR

Set right value in upper_th_value and lower_th_value before activating the compare enable bit.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Comparison Status Register

The results of comparison are stored in the output word named compare status register.

The two thresholds may be compared with the:

- current value of SSI register
- value of capture register 0
- value of capture register 1

NOTE: The compare results for all the three modes can only be handled by a firmware interrupt, the delay of the reaction depends on the interrupt priority and the system response time (for example, 1 ms).

The possible results are:

- Low: The value is less than the lower threshold value.
- Window: The value is between the upper and lower thresholds or equal to one of the two thresholds.
- High: The value is greater than the upper threshold.

The compare status register (%IWr.m.c.1) consists of:

Status register bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Compared element								C	apture	1	C	apture	0	SS	I Regis	ter
Comparison result								High	Win- dow	Low	High	Win- dow	Low	High	Wind ow	Low

Register Updates

When the validate bit is False (Low), the compare status register is cleared.

Update Time:


- The comparison with capture 0 and capture 1 registers values is performed every time the registers are loaded.
- The comparison with the SSI register occurs for each refreshed value (each 1 ms).

Modification of the Thresholds during the Operational Phase

If the application needs to modify the thresholds during the running of the SSI input, the **Compare Suspend Bit** holds the **Compare Status Register** during the modification of threshold.

Compare Status Register needs the **Compare Enable Bit** set active (1) and **Compare Suspend Bit** set inactive (0) to be updated. Both **Compare Enable Bit** and **Compare Suspend Bit** are set through the Output Word.

The following figure illustrates the actions of the compare_enable bit (%QWr.m.c.0.5) and the compare_suspend bit (%QWr.m.c.0.6):



When Compare Enable Bit is False, the compare status register is cleared.

When **Compare Suspend Bit** is true, the **compare status register** holds the previous result of comparison until this bit becomes "0" again.

The threshold is updated if the channel gets the falling edge of the **Compare Suspend Bit**. For example: at the moment that the **Compare Suspend Bit** turns from 1 to 0, the SSI module update the threshold with the newest value in %QW.

NOTE: The user must enter the thresholds which are reformatting (modulo, reduction, offset and direction reversed) if any reformatting function is applied.

Operating mode

After a **BMXEAE0300**'s rack power cut, the **Compare Suspend Bit** should be set to 1 and then to 0 so that the comparison could be done by the module.

SSI Status Register

Modulo Bit

This bit is used to detect the passing of modulo. It is set (active 1) when the SSI encoder value passes the modulo, and it does not return to 0 unless the application clears (reset) the flag by using the output command bit: Reset Modulo Flag.

Capture Event Bit

This bit is used to report the occurrence of a capture action. "1" indicates that there was a capture action, "0" means no capture occurred so far. Once it is set, this bit stays at "1" until it is cleared by the application by output command bit of Reset Capture Flag.

Frame Error Bit

This bit reports any detected error during the sequence. The Line_err bit is also reported via this bit. The detected line error, such as the drop of line, changes the status of Frame Error bit to "1".

NOTE: The BMX EAE 0300 module asserts a frame error (line drop) by seeing an all "1" frame (internally pull-up). This means in case the real input position is just an all "1" frame, the frame error bit will also be set and the current value (all "1") will not be updated to the SSI register. The position value will be updated once the encoder leaves the all "1" position.

The user is suggested to walk around the all "1" position by using the multi-turn encoder or set the appropriate modulo / reduction parameter.

NOTE: The Frame Error bit can also detect a wrong configuration of SSI data width. But this detection function depends on the SSI encoders. Some encoders support this function, while others do not fully support it.

Status Bit

This bit provided by the encoder, which follows the LSB in the sequence is usually used to indicate a detected error from the encoder.

NOTE: If the status bit is supported by the encoder, you should use it to detect when a wrong frame has been sent.

Parity Bit

This bit indicates a parity error. "1" means the occurrence of detected error.

NOTE: If the parity bit is supported by the encoder, you should use it to detect when the frame has been corrupted during transfer.

Event Sent To Application

Summary

The number of the event task must be declared in the module configuration screen.

The SSI module includes 6 sources of events:

Source Name	Comment
Modulo	Event when the SSI value passed modulo
SSI Low	Event when the SSI value is lower than the lower threshold
SSI Window	Event when the SSI value is within [lower threshold, upper threshold]
SSI High	Event when the SSI value is greater than the upper threshold
Capture 0	Event when capture register 0 updates
Capture 1	Event when capture register 1 updates

All the events sent by the module, regardless of the source, call the same single event task in the PLC.

There is normally only one type of event signaled per call. The source producing the call is determined in the event task via the Events Source variable. This variable is updated at the beginning of event task processing.

NOTE: If two or more event sources occur in the same 1 ms cycle, then multiple events will be sent (one event for one source).

Enable Event Function

EVT_SOURCES_ENABLING should be enabled if you want to use event function for the source. Event function is only possible with the topological data model (IODDT).

NOTE: For modulo and capture, the status bits MODULO_FLAG, CAPT_0_FLAG, and CAPT_1_FLAG only work when corresponding event source is enabled (EVT_MODULO_ENABLE, EVT_CAPT_0_ENABLE, and EVT_CAPT_0_ENABLE).

Event Validate Description

When an action comes from an external event, this action must be validated before affecting the application. There is one (Function)_Validation bit by function which can be impacted by an external event.

Example Using Capture CAP_IN

This function holds the current SSI value in the Capture 0 register.

- Valid_Capture0: When it is asserted as "1", it allows loading the current SSI value into the Capture 0 register consequential to the CAP_IN0 (see page 54). When it is "0", the value in the capture register 0 will not change.
- Valid_Capture1: When it is asserted as "1", it allows loading the current SSI value into the
 Capture 1 register consequential to the CAP_IN1 (see page 54). When it is "0", the value in the
 capture register 1 will not change.

NOTE: In order to make a capture happen, besides the validate bit, the corresponding configuration (%K) must be set also.

Output Block Functions


Overview

Every channel in the SSI module has one programmable output block that operates with the Compare Status Register and affects the behavior of physical outputs Qx for each channel.

There are two ways to control the output:

- From the application: the output corresponds to the status of the output bit from the output command bit.
- From the output function block: the user must enable the output block function. Then, the output corresponds to the status of the output bit from the function block.

The following figure shows the output function block Q0:



Configurable Functions

The operational Latch Mode must be chosen among 11 functions in configuration tab.

As stated, the output comes:

- Directly, from the application software (Normal Output): 1 function.
- From the output function block (Reflex Output): 10 functions.
 The output matches the state of the output bit in the output function block result.

The table below shows the configurable functions:

Function code	Programming
0	No reflex action (default)
1	SSI value low The output is high if the SSI value is less than the lower threshold.
2	SSI value in a window The output is high if the SSI value is between the upper and lower thresholds or equal to one of the two thresholds.
3	SSI value high The output is high if the SSI value is greater than the upper threshold.
4	Capture 0 low The output is high if the capture 0 value is less than the lower threshold.
5	Capture 0 in a window The output is high if the capture 0 value is between the upper and lower thresholds or equal to one of the two thresholds.
6	Capture 0 high The output is high if the capture 0 value is greater than the upper threshold.
7	Capture 1 low The output is high if the capture 1 value is less than the lower threshold.
8	Capture 1 in a window The output is high if the capture 1 value is between the upper and lower thresholds or equal to one of the two thresholds.
9	Capture 1 high The output is high if the capture 1 value is greater than the upper threshold.
10	Modulo Passing The output is high if the SSI encoder value changes from lower to upper than the modulo or from upper to lower direction.

Output Properties

The SSI module BMX EAE 0300 enables output signals to be adapted with three 24 Vdc field actuators.

It is possible to configure the following parameters for each output:

- Logic normal or logic reverse output polarity for each channel on the module
- Fallback mode and state for every module channel

Detected Error Recovery

Outputs Q0, Q1 and Q2 are current limited (0.5 A maximum).

A thermal shutdown protects each output.

When a short-circuit is detected on one of the output channels, the SSI module latches off the output channel.

If an output channel has been latched off because of short-circuit detection, the SSI module recovers from the short-circuit after the following sequence is processed:

- The short-circuit has been corrected
- To reset the detected error, the application must:
 - O Reset the output block enable bit if it is active
 - O Command the ouput to 0 Vdc (depends on the polarity).

NOTE: A minimum delay of 10 s occurs before the detected error is cleared.

Output Polarity Programming

By default, the polarity on all output channels is logic normal, where:

- 0 indicates that the physical actuator is off (the output signal is low)
- 1 indicates that the physical actuator is on (the output signal is high)

It is possible to configure the polarity parameter for each output during the channel configuration to "1" or "0".

Output Fallback Modes

The fallback modes are the predefined states to which the output channels revert when the channel is not controlled by the processor (for example, when communications are lost or when the processor is stopped).

The fallback mode of each output channel can be configured as one of the following modes:

- Predefined state: you may configure the fallback value as 0 or 1
- Hold last value: the output block function continues to operate according to the last received commands.

NOTE: By default, the fallback mode of the 3 output channels is Predefined state; the fallback value parameter is 0.

Chapter 6 Adjustment


Screen for the SSI Module BMX EAE 0300

At a Glance

This chapter presents the adjust screen for the SSI module BMX EAE 0300.

Illustration

The figure below presents the Adjust screen for the SSI module BMX EAE 0300 in absolute SSI encoder mode:



Description of the Screen

The following table presents the various parts of the above screen:

Number	Column	Function	
1	Label	These fields contain the name of each variable that may be adjusted. They may not be modified and can be accessed in both local and online modes.	
2	Tab	The tab in the foreground indicates the current mode. The current mode is therefore the adjust mode in this example.	
3	Symbol	These fields contain the mnemonic name of the variable. They may not be modified and can be accessed in both offline and online modes.	
4	Initial value	These fields display the value of the variable that the user has adjusted in offline mode. They are only accessible in online mode.	
5	Value	The function of these fields depends on the mode in which the user is working: In offline mode: these field are used to adjust the variable. In online mode: these field are used to display the current value of the variable.	
6	Unit	These fields contain the unit of each variable that may be configured. They may not be modified and can be accessed in both offline and online modes.	

Chapter 7

Debugging the SSI Module BMX EAE 0300


Debug Screen for the SSI Module BMX EAE 0300

At a Glance

This chapter presents the debug screen for the SSI module BMX EAE 0300. The Debug screen can only be accessed in online mode.

Illustration

The screen presents the debug screen for the SSI module BMX EAE 0300:



Description of the Screen

The following table presents the various parts of the Debug screen:

Number	Column	Function	
1	Reference	These fields contain the address of the variable in the application. They may not be modified.	
2	Label	These fields contain the name of each variable that may be configured. They may not be modified.	
3	Tab	The tab in the foreground indicates the current mode. The current mode is the debug mode in this example.	
4	Symbol	These fields contain the mnemonic name of the variable. They may not be modified.	
5	Value If the fields have a downward pointing arrow, you can select the value of each variable for various possible values in these fields. The various values can be accessed by clicking the arrow. A drop-down menu containing all the possible values is displayed and the unay then select the required value of the variable. If there is no downward pointing arrow, these fields simply display the current value of variable.		

Chapter 8

Diagnostic of the SSI Module BMX EAE 0300


Diagnostic Screen for the SSI Module BMX EAE 0300

At a Glance

This chapter presents the fault display screen for the SSI module BMX EAE 0300. A fault display screen of module may only be accessed in online mode.

Illustration

The figure below presents the Diagnostic Screen for the SSI module BMX EAE 0300 in position control mode.



Description of the Screen

The following table presents the various parts of the Diagnostic screen:

Number	Column	Function	
1	Internal faults	These fields display the module's active detected internal errors.	
2	Tab	This tab in the foreground indicates the current mode. The current mode is the Fault display mode in this example.	
3	External faults	These fields display the module's active detected external errors.	
4	Other faults	These fields display the module's active detected errors, other than internal and detected external errors.	

Description of the Fault Type

The following table presents the list of detected error types:

Number	Fault type	Name	Display
0	External	EXT0_FLT	External Fault on Inputs
1	External	EXT1_FLT	External Fault on Outputs
2	Internal	INTERNAL_FLT	Faulty channel
3	Internal	CONF_FLT	Detected hardware or software configuration fault
4	Internal	COM_FLT	Module missing or off (interruption of communication with PLC)
5	Internal	APPLI_FLT	Application mistake (configuration or adjustment)
6	External	Field Supply	Field supply low voltage
7	External	S_Circuit OUT	Reflex Output (24 Vdc) inoperative after Short Circuit

Chapter 9

The Language Objects of the SSI Function

Overview

This chapter describes the language objects associated to the SSI module BMX EAE 0300 tasks as well as the different ways of using them.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	The Language Objects and IODDT of the SSI Function	74
9.2	Language Objects and IODDTs Associated with the SSI Function	83
9.3	Language Objects and Device DDT Associated with the SSI Function	91

Section 9.1

The Language Objects and IODDT of the SSI Function

At a Glance

This section presents an overview of the position control IODDT languages and objects.

What Is in This Section?

This section contains the following topics:

Topic	Page
Introducing Language Objects for Application-Specific SSI	75
Implicit Exchange Language Objects Associated with the Application-Specific Function	76
Explicit Exchange Language Objects Associated with the Application-Specific Functions	77
Management of Exchanges and Reports with Explicit Objects	79

Introducing Language Objects for Application-Specific SSI

Language Object Types

There are two types of language objects:

- Implicit Exchange Objects: these objects are automatically exchanged on each cycle revolution
 of the task associated with the module
 Implicit exchanges concern the inputs/outputs of the module (measurement results, information
 and commands). These exchanges enable the debugging of the counting modules.
- Explicit Exchange Objects: these objects are exchanged on the application's request, using
 explicit exchange instructions
 Explicit exchanges enable the module to be set and diagnosed.

Implicit Exchange Language Objects Associated with the Application-Specific Function

At a Glance

An integrated application-specific interface or the addition of a module automatically enhances the language objects application used to program this interface or module.

These objects correspond to the input/output images and software data of the module or integrated application-specific interface.

Module Inputs

The module inputs ($\S I$ and $\S IW$) are updated in the PLC memory at the start of the task, the PLC being in RUN or STOP mode.

The outputs (%Q and %QW) are updated at the end of the task, only when the PLC is in RUN mode.


NOTE:

When the task occurs in STOP mode, either of the following are possible, depending on the configuration selected:

- outputs are set to fallback position (fallback mode)
- outputs are maintained at their last value (maintain mode)

Operating Cycle of a PLC Task

The following diagram shows the cyclical execution of a PLC task.



Explicit Exchange Language Objects Associated with the Application-Specific Functions

Introduction

Explicit exchanges are performed at the user program's request using these instructions:

- READ_STS (read status words)
- WRITE_PARAM (write adjustment parameters)
- READ_PARAM (read adjustment parameters)
- SAVE_PARAM (save adjustment parameters)
- RESTORE_PARAM (restore adjustment parameters)

For details about instructions, refer to *EcoStruxure™ Control Expert, I/O Management, Block Library.*

These exchanges apply to a set of %MW objects of the same type (status, commands or parameters) that belong to a channel.

NOTE:


These objects can:

- provide information about the module (for example, type of channel detected error)
- define the module's operating modes (save and restore adjustment parameters in the process of application)

NOTE: In order to avoid several simultaneous explicit exchanges for the same channel, it is necessary to test the value of the word EXCH_STS (%MWr.m.c.0) of the IODDT associated to the channel before calling any EF addressing this channel.

General Principle for Using Explicit Instructions

The diagram below shows the different types of explicit exchanges that can be made between the application and module:



(1) Only with READ_STS instruction.

Managing Exchanges

During an explicit exchange, it is necessary to check performance to ensure data is only taken into account when the exchange has been correctly executed.

To do this, two types of information is available:

- information concerning the exchange in progress (see page 81)
- the exchange report (see page 82)

The following diagram describes the management principle for an exchange:



NOTE: In order to avoid several simultaneous explicit exchanges for the same channel, it is necessary to test the value of the word EXCH_STS (%MWr.m.c.0) of the IODDT associated to the channel before calling any EF addressing this channel.

Management of Exchanges and Reports with Explicit Objects

At a Glance

When data is exchanged between the PLC memory and the module, the module may require several task cycles to acknowledge this information. All IODDTs use two words to manage exchanges:

- EXCH STS (%MWr.m.c.0): exchange in progress
- EXCH RPT (%MWr.m.c.1): report


NOTE:

Depending on the localization of the module, the management of the explicit exchanges (for example, %MW0.0.MOD.0.0) are not detected by the application:

- For in-rack modules, explicit exchanges are done immediately on the local PLC bus and are finished before the end of the execution task. The READ_STS, for example, is always finished when the %MW0.0.mod.0.0 bit is checked by the application.
- For remote bus (Fipio for example), explicit exchanges are not synchronous with the execution task, so the detection is possible by the application.

Bits for Managing Exchanges

The illustration below shows the different significant bits for managing exchanges:



Description of Significant Bits

Each bit of the words EXCH_STS (%MWr.m.c.0) and EXCH_RPT (%MWr.m.c.1) is associated with a type of parameter:


- Rank 0 bits are associated with the status parameters:
 - The STS_IN_PROGR bit (%MWr.m.c.0.0) indicates whether a read request for the status words is in progress.
 - O The STS_ERR bit (%MWr.m.c.1.0) specifies whether a read request for the status words is accepted by the module channel.
- Rank 2 bits are associated with the adjustment parameters:
 - O The ADJ_IN_PROGR bit (%MWr.m.c.0.2) indicates whether the adjustment parameters are being exchanged with the module channel (via WRITE_PARAM, READ_PARAM, SAVE_PARAM or RESTORE PARAM).
 - O The ADJ_ERR bit (%MWr.m.c.1.2) specifies whether the adjustment parameters are accepted by the module. If the exchange is correctly executed, the bit is set to 0.
- Rank 15 bits indicate a reconfiguration on channel **c** of the module from the console (modification of the configuration parameters + cold start-up of the channel).

NOTE: r represents the rack number, **m** the position of the module in the rack, while **c** represents the channel number in the module.

NOTE: Exchange and report words also exist at module level EXCH_STS (%MWr.m.MOD) and EXCH RPT (%MWr.m.MOD.1) as per IODDT type T GEN MOD.

Data Exchange Example

Phase 1: Sending data by using the WRITE PARAM instruction



When the instruction is scanned by the PLC processor, the **Exchange in progress** bit is set to 1 in %MWr.m.c.

Phase 2: Analysis of the data by the I/O module.



When the data is exchanged between the PLC memory and the module, acknowledgement by the module is managed by the ADJ ERR bit (%MWr.m.c.1.2).

This bit's values are:

- 0: correct exchange
- 1: detected error in the exchange

NOTE: There is no adjustment parameter at module level.

Execution Indicators for an Explicit Exchange: EXCH_STS

The table below shows the control bits of the explicit exchanges: EXCH STS (%MWr.m.c.0)

Standard symbol	Туре	Access	Meaning	Address
STS_IN_PROGR	BIT	R	Reading of channel status words in progress	%MWr.m.c.0.0
Unused	BIT	R	Unused	%MWr.m.c.0.1
ADJUST_IN_PROGR	BIT	R	Adjust parameters exchange in progress	%MWr.m.c.0.2
RECONF_IN_PROGR	BIT	R	Reconfiguration of the module in progress	%MWr.m.c.0.15

NOTE: If the module is not present or is disconnected, explicit exchange objects (READ_STS for example) are not sent to the module (STS_IN_PROG (%MWr.m.c.0.0) = 0), but the words are refreshed.

Explicit Exchange Report: EXCH_RPT

The table below shows the report bits: EXCH RPT (%MWr.m.c.1)

Standard symbol	Туре	Access	Meaning	Address
STS_ERR	BIT	R	Detected error reading channel status words (1 = reading not done)	%MWr.m.c.1.0
Unused	BIT	R	Unused	%MWr.m.c.1.1
ADJUST_ERR	BIT	R	Detected error during an adjust parameter exchange (1 = exchange not done)	%MWr.m.c.1.2
RECONF_ERR	BIT	R	Error during reconfiguration of the channel (1 = reconfiguration not done)	%MWr.m.c.1.15

SSI Module Use

The following table describes what happens between a SSI module and the system after a power-on:

Step	Action
1	Power on.
2	The system sends the configuration parameters.
3	The system sends the adjust parameters by WRITE_PARAM method. Note: When the operation is finished, the bit %MWr.m.c.0.2 switches to 0.

If, in the begining of your application, you use a WRITE_PARAM command, you must wait until the bit %MWr.m.c.0.2 switches to 0.

Section 9.2

Language Objects and IODDTs Associated with the SSI Function

At a Glance

An integrated application-specific interface or the addition of a module automatically enhances the language objects application used to program this interface or module.

These objects correspond to the input/output images and software data of the module or integrated application-specific interface.

What Is in This Section?

This section contains the following topics:

Topic	Page
General Information	84
Details of the Language Objects of the IODDT of Type T_GEN_MOD	85
Exchange Objects for the T_SSI_BMX IODDT	86

General Information

General

The SSI modules have two associated IODDTs. These IODDTs are predefined by the manufacturer and contains language objects for inputs/outputs belonging to the channel of an application-specific module.

The IODDT associated with the SSI modules are:

- language objects at Module Level of the SSI Module (T GEN MOD)
- language objects associated with the SSI channel 0, 1 or 2 (T SSI BMX)

IODDT variables can be created in two different ways using the:

- I/O objects (see page 109) tab
- Data Editor (see page 114)

Each IODDT contains a set of language objects allowing its operation to be controlled and checked.

Details of the Language Objects of the IODDT of Type T_GEN_MOD

Introduction

The Modicon X80 modules have an associated IODDT of type T_GEN_MOD.

Observations

In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.

Some bits are not used.

List of Objects

The table below presents the objects of the IODDT.

Standard Symbol	Туре	Access	Meaning	Address
MOD_ERROR	BOOL	R	Module detected error bit	%lr.m.MOD.ERR
EXCH_STS	INT	R	Module exchange control word	%MWr.m.MOD.0
STS_IN_PROGR	BOOL	R	Reading of status words of the module in progress	%MWr.m.MOD.0.0
EXCH_RPT	INT	R	Exchange report word	%MWr.m.MOD.1
STS_ERR	BOOL	R	Event when reading module status words	%MWr.m.MOD.1.0
MOD_FLT	INT	R	Internal detected errors word of the module	%MWr.m.MOD.2
MOD_FAIL	BOOL	R	module inoperable	%MWr.m.MOD.2.0
CH_FLT	BOOL	R	Inoperative channel(s)	%MWr.m.MOD.2.1
BLK	BOOL	R	Terminal block incorrectly wired	%MWr.m.MOD.2.2
CONF_FLT	BOOL	R	Hardware or software configuration anomaly	%MWr.m.MOD.2.5
NO_MOD	BOOL	R	Module missing or inoperative	%MWr.m.MOD.2.6
EXT_MOD_FLT	BOOL	R	Internal detected errors word of the module (Fipio extension only)	%MWr.m.MOD.2.7
MOD_FAIL_EXT	BOOL	R	Internal detected error, module unserviceable (Fipio extension only)	%MWr.m.MOD.2.8
CH_FLT_EXT	BOOL	R	Inoperative channel(s) (Fipio extension only)	%MWr.m.MOD.2.9
BLK_EXT	BOOL	R	Terminal block incorrectly wired (Fipio extension only)	%MWr.m.MOD.2.10
CONF_FLT_EXT	BOOL	R	Hardware or software configuration anomaly (Fipio extension only)	%MWr.m.MOD.2.13
NO_MOD_EXT	BOOL	R	Module missing or inoperative (Fipio extension only)	%MWr.m.MOD.2.14

Exchange Objects for the T_SSI_BMX IODDT

At a Glance

The tables below present the ${\tt T_SSI_BMX}$ types IODDT exchange objects which are applicable to the SSI module BMX EAE 0300.

In general, the meaning of the bits is given for bit status 1.

Not all bits are used.

Channel Objects

The table below shows the meaning of the channel objects:

Standard symbol	Туре	Access	Meaning	Language object
-	-	R	Language element of channel level used for explicit exchanges READ_STS, READ_PARAM, WRITE_PARAM, SAVE_PARAM, and RESTORE_PARAM	%CHr.m.c
CH_ERROR	BOOL	R	Channel detected error bit when this bit is at 1.	%Ir.m.c.ERR

Counter Value and Sensor Values

The table below presents the current counting value and the captured values:

Standard symbol	Туре	Access	Meaning	Language object
SSI_CURRENT_VALUE	UDINT	R	Current value of SSI register	%IDr.m.c.2
CAPT_0_VALUE	UDINT	R	Value latched into Capture register 0	%IDr.m.c.4
CAPT_1_VALUE	UDINT	R	Value latched into Capture register 1	%IDr.m.c.6

%Ir.m.c bits

The table below presents the meanings of the %Ir.m.c bits:

Standard symbol	Туре	Access	Meaning	Language object
ST_REFLEX_OUTPUT	EBOOL	R	Voltage level applied to the 24 Vdc channel output 0: 0 Vdc 1: 24 Vdc	%Ir.m.c.0
ST_OUTPUT_LATCH	EBOOL	R	Logical state of internal channel Latch	%Ir.m.c.1
ST_CAPT_INPUT_0	EBOOL	R		%Ir.m.c.2
ST_CAPT_INPUT_1	EBOOL	R		%Ir.m.c.3

SSI_Status, %IWr.m.c.0 Word

The following table presents the meanings of the bits of the $\mbox{\ensuremath{\$IWr.m.c.0}}$ status word, named $\mbox{\ensuremath{\$SI_STATUS:}}$

Standard symbol	Туре	Access	Meaning	Language object
Reserved	_	_	Reserved	%IWr.m.c.0.0
MODULO_FLAG	BOOL	R	0: no modulo passing 1: modulo passing	%IWr.m.c.0.1
			NOTE: To enable this flag bit, EVT_MODULO_ENABLE should be set to 1.	
CAPT_0_FLAG	BOOL	R	0: the capture 0 register is not updated 1: the capture 0 register is updated	%IWr.m.c.0.2
			NOTE: To enable this flag bit, EVT_CAPT_0_ENABLE should be set to 1.	
CAPT_1_FLAG	BOOL	R	0: the capture 1 register is not updated 1: the capture 1 register is updated	%IWr.m.c.0.3
			NOTE: To enable this flag bit, EVT_CAPT_1_ENABLE should be set to 1.	
SSI_FRAME_ERR_FLAG	BOOL	R	0: the SSI frame is correct 1: the line error such as the drop of line exists	%IWr.m.c.0.4
SSI_STATUS_ERR_FLAG	BOOL	R	indicates a detected read data error	%IWr.m.c.0.5
SSI_PARITY_ERR_FLAG	BOOL	R	0: parity correct 1: parity error	%IWr.m.c.0.6

COMPARE_STATUS, %IWr.m.c.1 Word

The following table presents the meanings of the bits of the $\mbox{\ensuremath{\$IWr.m.c.1}}$ status word, named COMPARE_STATUS:

Standard symbol	Туре	Access	Meaning	Language object
SSI_LOW	BOOL	R	Current SSI value less than lower threshold (%QDr.m.c.4)	%IWr.m.c.1.0
SSI_WIN	BOOL	R	Current SSI value is between lower threshold (%QDr.m.c.4) and upper threshold (%QDr.m.c.6)	%IWr.m.c.1.1
SSI_HIGH	BOOL	R	Current SSI value greater than upper threshold (%QDr.m.c.6)	%IWr.m.c.1.2
CAPT_0_LOW	BOOL	R	Value captured in register 0 is less than lower threshold (%QDr.m.c.4)	%IWr.m.c.1.3
CAPT_0_WIN	BOOL	R	Value captured in register 0 is between lower threshold (%QDr.m.c.4) and upper threshold (%QDr.m.c.6)	%IWr.m.c.1.4
CAPT_0_HIGH	BOOL	R	Value captured in register 0 is greater than upper threshold (%QDr.m.c.6)	%IWr.m.c.1.5
CAPT_1_LOW	BOOL	R	Value captured in register 1 is less than lower threshold (%QDr.m.c.4)	%IWr.m.c.1.6
CAPT_1_WIN	BOOL	R	Value captured in register 1 is between lower threshold (%QDr.m.c.4) and upper threshold (%QDr.m.c.6)	%IWr.m.c.1.7
CAPT_1_HIGH	BOOL	R	Value captured in register 1 is greater than upper threshold (%QDr.m.c.6)	%IWr.m.c.1.8
LT_HIGH	BOOL	R	Lower threshold (%QDr.m.c.4) is greater than upper threshold (%QDr.m.c.6)	%IWr.m.c.1.9

EVT_SOURCES, %IWr.m.c.10 Word

The following table presents the meanings of the bits of the $\mbox{\ensuremath{\$IWr.m.c.10}}$ word, named $\mbox{\ensuremath{$EVT_SOURCES:}}$

Standard symbol	Туре	Access	Meaning	Language object
Reserved	-	_	Reserved	%IWr.m.c.10.0
EVT_MODULO	BOOL	R	Event due to modulo switch	%IWr.m.c.10.1
Reserved	BOOL	R	Reserved	%IWr.m.c.10.2
EVT_SSI_LOW	BOOL	R	Event due to SSI value being less than lower threshold	%IWr.m.c.10.3
EVT_SSI_WINDOW	BOOL	R	Event due to SSI value being between the two thresholds	%IWr.m.c.10.4
EVT_SSI_HIGH	BOOL	R	Event due to SSI value being greater than upper threshold	%IWr.m.c.10.5
EVT_CAPT_0	BOOL	R	Event due to capture function 0	%IWr.m.c.10.6
EVT_CAPT_1	BOOL	R	Event due to capture function 1	%IWr.m.c.10.7
EVT_OVERRUN	BOOL	R	Events have been lost	%IWr.m.c.10.9

Output Thresholds

The table below presents the output thresholds:

Standard symbol	Туре	Access	Meaning	Language object
LOWER_TH_VALUE	UDINT	R/W	Lower threshold value	%QDr.m.c.4
UPPER_TH_VALUE	UDINT	R/W	Upper threshold value	%QDr.m.c.6

%Qr.m.c.d Words

The following table presents the meanings of the output words:

Standard symbol	Туре	Access	Meaning	Language object
OUTPUT_FORCE	EBOOL	R/W	1: the reflex output forced to "1". 0 and reflex block is disables: the reflex output returns	%Qr.m.c.0
REFLEX_BLOCK_ENABLE	EBOOL	R/W	1: Output Block function enabled	%Qr.m.c.1

FUNCTIONS ENABLING, %QWr.m.c.0 Word

The following table presents the meanings of the bits of the QWr.m.c.0 word, named FUNCTIONS ENABLING:

Standard symbol	Туре	Access	Meaning	Language object
Reserved	_	_	Reserved	%QWr.m.c.0.0
Reserved	_	-	Reserved	%QWr.m.c.0.1
Reserved	_	-	Reserved	%QWr.m.c.0.2
VALID_CAPT_0	BOOL	R/W	Capture authorization in the capture0 register	%QWr.m.c.0.3
VALID_CAPT_1	BOOL	R/W	Capture authorization in the capture1 register	%QWr.m.c.0.4
COMPARE_ENABLE	BOOL	R/W	Comparators operation authorization	%QWr.m.c.0.5
COMPARE_SUSPEND	BOOL	R/W	Comparator frozen at its last value	%QWr.m.c.0.6

EVT_SOURCES_ENABLING, %QWr.m.c.1 Word

The following table presents the meanings of the bits of the QWr.m.c.1 word, named $EVT_SOURCES_ENABLING:$

Standard symbol	Туре	Access	Meaning	Language object
Reserved	_	-	Reserved	%QWr.m.c.1.0
EVT_MODULO_ENABLE	BOOL	R/W	EVENT task called when there is a SSI module passing	%QWr.m.c.1.1
Reserved	_	-	Reserved	%QWr.m.c.1.2
EVT_SSI_LOW_ENABLE	BOOL	R/W	EVENT task call when the SSI value is less than lower threshold	%QWr.m.c.1.3
EVT_SSI_WINDOW_ENABLE	BOOL	R/W	EVENT task call when the SSI value is between the lower and upper threshold	%QWr.m.c.1.4
EVT_SSI_HIGH_ENABLE	BOOL	R/W	EVENT task call when the SSI value is greater than the upper threshold	%QWr.m.c.1.5
EVT_CAPT_0_ENABLE	BOOL	R/W	EVENT task call during capture in register 0	%QWr.m.c.1.6
EVT_CAPT_1_ENABLE	BOOL	R/W	EVENT task call during capture in register 1	%QWr.m.c.1.7

Section 9.3

Language Objects and Device DDT Associated with the SSI Function

At a Glance

This section presents the device DDT of the module **BMX EAE 0300** and the DDT used for the variables in explicit exchanges.

What Is in This Section?

This section contains the following topics:

Topic	Page
Device DDT for BMX EAE 0300 Module	92
MOD_FLT Byte Description	96
DDT Description for Explicit Exchange	97

Device DDT for BMX EAE 0300 Module

Introduction

The Device DDT is a predefined DDT that describes the I/O language elements of the I/O module. This data type is represented in a structure which provides bits and register view.

This topic describes the structure of the implicit Control Expert Device DDT for the Synchronous Serial Interface (SSI) module **BMX EAE 0300**.

T_M_SSI_3 Device DDT Description

The following table gives the structure of the T_M_SSI_3 Device DDT:

Name	Туре	Description
MOD_HEALTH	BOOL	0 = the module has a detected error
		1 = the module is operating correctly
MOD_FLT	ВУТЕ	Internal detected errors <i>(see page 96)</i> of the module.
SSI_CH	ARRAY [02] of T_M_SSI_STD_CH (see page 93)	SSI channels

T_M_SSI_STD_CH

The following table gives the structure of T_M_SSI_STD_CH:

Name	Туре	Bit	Description	Access
FCT_TYPE	WORD		Unused	read
CH_HEALTH	BOOL		0 = the channel has a detected error	read
			1 = the channel is operating correctly	
ST_REFLEX_OUTPUT	EBOOL	-	Voltage level applied to the 24 Vdc channel output: ■ 0 = 0 Vdc ■ 1 = 24 Vdc	read
ST_OUTPUT_LATCH	EBOOL	_	Logical state of internal channel Latch	read
ST_CAPT_INPUT_0	EBOOL	=	Physical input 0 state.	read
ST_CAPT_INPUT_1	EBOOL	_	Physical input 1 state.	read
SSI_STATUS	INT		Main status register.	read
MODULO_FLAG	BOOL	1	Flag set by a modulo crossing event: • 0 = no modulo passing • 1 = modulo passing	
CAPT_0_FLAG	BOOL	2	Flag set by capture 0 register update: ■ 0 = the capture 0 register is not updated ■ 1 = the capture 0 register is updated	
			NOTE: To enable this flag bit, EVT_CAPT_0_ENABLE should be set to 1.	
CAPT_1_FLAG	BOOL	3	Flag set by capture 1 register update: • 0 = the capture 1 register is not updated • 1 = the capture 1 register is updated	
			NOTE: To enable this flag bit, EVT_CAPT_1_ENABLE should be set to 1.	
SSI_FRAME_ERR_FLAG	BOOL	4	Flag set by a detected SSI frame error: ■ 0 = the SSI frame is correct ■ 1 = the line error such as the drop of line exists	
SSI_STATUS_ERR_FLAG	BOOL	5	Flag set by a detected read data error.	
SSI_PARITY_ERR_FLAG	BOOL	6	Flag set by a detected SSI parity error: • 0 = parity is correct • 1 = detected parity error	

Name	Туре	Bit	Description	Access
COMPARE_STATUS	INT		Field of comparison result bits.	read
SSI_LOW	BOOL	0	Numeral current value is less than the lower threshold (LOWER_TH_VALUE).	
SSI_WIN	BOOL	1	Numeral current value is between lower threshold (LOWER_TH_VALUE) and upper threshold (UPPER_TH_VALUE).	
SSI_HIGH	BOOL	2	Numeral current value is greater than the upper threshold (UPPER_TH_VALUE).	
CAPT_0_LOW	BOOL	3	Value captured in register 0 is less than lower threshold.	
CAPT_0_WIN	BOOL	4	Value captured in register 0 is between lower threshold and upper threshold.	
CAPT_0_HIGH	BOOL	5	Value captured in register 0 is greater than the upper threshold.	
CAPT_1_LOW	BOOL	6	Value captured in register 1 is less than lower threshold.	
CAPT_1_WIN			Value captured in register 1 is between lower threshold and upper threshold.	
CAPT_1_HIGH	BOOL	8	Value captured in register 1 is greater than the upper threshold.	
LT_HIGH	BOOL 9		Lower threshold is greater than the upper threshold.	
SSI_CURRENT_VALUE	UDINT		Main numerical current value of SSI register.	read
CAPT_0_VALUE	UDINT		Numerical current value latched into capture register 0.	read
CAPT_1_VALUE	UDINT		Numerical current value latched into capture register 1.	read
OUTPUT_FORCE	EBOOL		Force OUTPUT to logical active high state: 1 = the reflex output forced to 1. 0 and reflex block is disable = the reflex output returns.	read/write
REFLEX_BLOCK_ENABLE	EBOOL		 Enable the reflex block function: 1 = output block function enabled. 0 = output block function disabled. 	read/write
FUNCTIONS_ENABLING	INT		Field of enable function bits.	read/write
VALID_CAPT_0	BOOL	3	Authorizes captures into the capture 0 register.	
VALID_CAPT_1	BOOL	4	Authorizes captures into the capture 1 register.	
COMPARE_ENABLE	BOOL	5	Authorizes comparators operation.	
COMPARE_SUSPEND	BOOL	6	Hold comparator at latest result.	

Name	Туре	Bit	Description	Access
EVT_SOURCES_ENABLING	INT		Field of enable event bits.	read/write
EVT_MODULO_ENABLE	BOOL	1	Call event task when counter roll over.	
EVT_SSI_LOW_ENABLE	BOOL	3	Call event task when main value goes less than the lower threshold.	
EVT_SSI_WINDOW_ENABLING	BOOL	4	Call event task when main value goes within the thresholds.	
EVT_SSI_HIGH_ENABLE	BOOL	5	Call event task when main value goes greater than the thresholds.	
EVT_CAPT_0_ENABLE	BOOL	6	Call event task when a capture in register 0 occurs.	
			NOTE: Even if event processing is not supported with device DDT, this bit enable CAPT_0_FLAG to be set to 1 when ST_CAPT_INPUT_0 is at 1.	
EVT_CAPT_1_ENABLE	BOOL	Call event task when a capture in register 1 occurs.		
			NOTE: Even if event processing is not supported with device DDT, this bit enable CAPT_1_FLAG to be set to 1 when ST_CAPT_INPUT_1 is at 1.	
SSI_STATUS_CLEAR	INT	•	Field of clear flag bits.	read/write
MODULO_CLEAR	BOOL	1	Clear the modulo flag of SSI.	
CAPT_0_CLEAR	BOOL	2	Clear the capture 0 flag of SSI status.	
CAPT_1_CLEAR	BOOL	3	Clear the capture 1 flag of SSI status.	
SSI_FRAM_ERR_CLEAR	BOOL	4	Clear the SSI frame detected error flag.	
SSI_STATUS_ERR_CLEAR	BOOL	5	Clear the SSI status detected error flag.	
SSI_PARITY_ERR_CLEAR	BOOL	6	Clear the SSI parity detected error flag.	
LOWER_TH_VALUE	DINT		Value of the lower threshold.	read/write
UPPER_TH_VALUE	DINT		Value of the upper threshold.	read/write

MOD_FLT Byte Description

MOD_FLT Byte in Device DDT

MOD_FLT byte structure:

Bit	Symbol	Description
0	MOD_FAIL	 1: Internal detected error or module failure detected. 0: No detected error
1	CH_FLT	1: Inoperative channels.0: Channels are operative.
2	BLK	 1: Terminal block detected error. 0: No detected error. NOTE: This bit may not be managed.
3	-	 1: Module in self-test. 0: Module not in self-test. NOTE: This bit may not be managed.
4	_	Not used.
5	CONF_FLT	 1: Hardware or software configuration detected error. 0: No detected error.
6	NO_MOD	 1: Module is missing or inoperative. 0: Module is operating. NOTE: This bit is managed only by modules located in a remote rack with a
		BME CRA 312 10 adapter module. Modules located in the local rack do not manage this bit that remains at 0.
7	_	Not used.

DDT Description for Explicit Exchange

Introduction

This section describes the DDT type used for the variables connected to dedicated EFB parameter in an explicit exchange:

DDT Type	Explicit Exchange Function	EFB	Parameter
T_M_SSI_CH_STS	Read module/channel status	READ_STS_MX	STS
T_M_SSI_CH_PRM	Read parameter ⁽¹⁾	READ_PARAM_MX	PARAM
	Write parameter ⁽¹⁾	WRITE_PARAM_MX	
	Restore parameter ⁽¹⁾	RESTORE_PARAM_MX	
	Save parameter ⁽¹⁾	SAVE_PARAM_MX	

⁽¹⁾ Parameter management is only possible for explicit exchange with I/O modules in M580 local rack.

NOTE: Targeted channel address (ADDR) can be managed with ADDMX (see EcoStruxure ™ Control Expert, Communication, Block Library) EF (connect the output parameter OUT to the input parameter ADDR of the communication functions).

T_M_SSI_CH_STS DDT Description

Name	Туре	Bit	Meaning	Access
CH_FLT	INT		Channel faults	read
EXTERNAL_FLT_INPUTS	BOOL	0	Detected error on the inputs.	
EXTERNAL_FLT_OUTPUTS	BOOL	1	Detected error on the outputs.	
INTERNAL_FLT	BOOL	4	detected internal error, the channel is inoperative.	
CONF_FLT	BOOL	5	detected hardware or software configuration error.	
COM_FLT	BOOL	6	detected bus communication error.	
APPLI_FLT	BOOL	7	detected error in application (adjustment or configuration)	
COM_EVT_FLT	BOOL	8	Communication detected error on event.	
OVR_EVT_CPU	BOOL	9	Overrun detected error on CPU event.	
OVR_CPT_CH	BOOL	10	Overrun detected error on channel event.	
CH_FLT_2	INT		execution control flags	read
SUPPLY_FLT	BOOL	2	detected field supply low voltage.	
SHORT_CIRCUIT_OUT	BOOL	3	Short circuit on reflex output (24 Vdc).	

T_M_SSI_CH_PRM DDT Description

The following table shows the T_M_SSI_CH_PRM structure status word bits:

Name	Туре	Bit	Meaning	Access
SSI_OFFSET	UDINT	_	Set the offset of the SSI value	read/write

Part III

Quick Start: SSI Module BMX EAE 0300 Implementation Example

Overview

This part provides an example using the SSI module BMX EAE 0300.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
10	Example Overview	101
11	Hardware Installation	105
12	Configuring the SSI Module BMX EAE 0300 on Control Expert	109
13	Programming the Example	113
14	Diagnostic and Debugging	119

Chapter 10 Example Overview

At a Glance

This chapter describes an overview of the example using the SSI module.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Example Introduction	102
Application Background	103

Example Introduction

At a Glance

The objective of the example is to give a full review of the SSI module implementation by creating an operational program.

This example describes the following steps:

- Description of the process
- Hardware installation
- Software configuration
- Programming
- Diagnosis and debugging

NOTE: This example will not cover the installation of the M340 controller, the other expansions modules nor the calibration of the SSI encoder.

Requirements

The hardware needed to do this example is:

- Modicon X80 SSI module (BMX EAE 0300)
- An SSI encoder and its necessary cables
- A M340 controller with an digital I/O expansion
- A drive
- A computer with Control Expert installed


NOTE: Basic knowledge of Control Expert programming and M340 controller installation is required for this example.

Application Background

Overview

The application example is a position control for the inlet gate of a dam using the SSI absolute encoder and Modicon X80 SSI interface module.

This system has an axis equipped with a drive for positioning the gate within the Open and the Close limits, in order to open, partially open or close the door for water inlet management.



Process Description

The position of the gate is managed by a drive, and this drive is controlled with 3 buttons:

Open This button commands the drive to open the gate (Motor+)


Close This button commands the drive to close the gate (Motor-)

Stop This button commands the drive to stop and activates the drive brake (Brake)

The position of the gate is measured with an SSI absolute encoder.

The encoder data range of SSI absolute encoder is calibrated and scaled to the distance between the Open and the Close limits.

When the gate moves up or down, the SSI encoder installed at the gearbox shaft then translates the position into its encoder data before sending it to SSI interface module for position supervision and control.



Chapter 11

Hardware Installation

Overview

This chapter concerns the hardware installation, mounting and wiring of the SSI module BMX EAE 0300.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Mounting the Module and the Terminal Block	106
Wiring Diagram of the Process	107

Mounting the Module and the Terminal Block


At a Glance

This part is fully described in the module installation (see page 23).


Wiring Diagram of the Process

Wiring Diagrams

The wiring diagram below shows the wiring of an SSI encoder to the SSI module:



The wiring diagram below shows the wiring of the necessary inputs and outputs of this example to a digital I/O module:



Digital I/O Module


Chapter 12

Configuring the SSI Module BMX EAE 0300 on Control Expert


Configuration of the SSI Module BMX EAE 0300

Module Selection

In order to add a BMX EAE 0300 module, a project with an M340 controller has to be created. Once created, follow this procedure in order to add the SSI module:




NOTE: For the purpose of the example, also add a digital I/O module to the configuration.



Configuring the Module


Once the module is added to the controller configuration, it is necessary to set which SSI channel will be used:



Create the I/O objects

In order to have access to the I/O of the module, it is necessary to declare the %CH object.

The table below shows the procedure for declaring the I/O Derived Variable:



Chapter 13

Programming the Example

Overview

This chapter provides a program to simulate the process.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Declaration of Variables	114
Creating the Program	115
Transferring the Project between the Terminal and the PLC	116

Declaration of Variables

At a Glance

All of the variables used in the different sections of the program must be declared.

Undeclared variables cannot be used in the program.


NOTE: For more information, refer to chapter *Data Editor* (see EcoStruxure ™ Control Expert, Operating Modes).

Variables Used for the Application

The following table shows the details of the variables used in the application.

Variable	Туре	Definition		
EDT variables				
Open	BOOL	Open command for the inlet gate		
Close	BOOL	Close command for the inlet gate		
Stop	BOOL	Stop command for the inlet gate		
Motor_Forward	BOOL	Open the inlet gate (Motor+)		
Motor_Backward	BOOL	Close the inlet gate (Motor-)		
Brake	BOOL	Blocks the inlet gate		
Open_Limit	UDINT	Open limit		
Close_Limit	UDINT	Close limit		
IODDT variable				
Gate_Position	T_SSI_BMX	IODDT of type T_SSI_BMX for the %CH0.1.0 address		

The following screen shows the application variables and their address created using the data editor:




NOTE: Click on \blacksquare in front of the derived variable Gate_Position to expand the I/O objects list.

Creating the Program

Illustration of the Program Section

This section below is part of the MAST task.

It has no condition defined for it so it is permanently executed:



Transferring the Project between the Terminal and the PLC

At a Glance

Transferring a project allows you to copy the current project from the terminal to the current PLC's memory (PLC that has its address selected).

Project Analysis and Generation

To perform analysis and generation of a project at the same time, carry out the following actions:

Step	Action
1	Activate the Rebuild All Project command in the Build menu. Result: the project is analyzed and generated by the software.
2	Detected errors are displayed in the information window at the bottom of your screen.


Project Backup

To back up the project, carry out the following actions:

Step	Action
1	Activate the Save As command in the File menu.
2	If necessary, select the directory to which the project will be saved (disk and path).
3	Enter the file name: EXAMPLE_SSI .
4	Confirm with Save. Result: the project is saved as EXAMPLE_SSI.STU.

Transferring the Project to the PLC

You must carry out the following actions to transfer the current project to a PLC:




Chapter 14

Diagnostic and Debugging

Monitor the Application

At a Glance

Create an operator screen for the application:



NOTE: For more information, refer to chapter *Operator screens* (see EcoStruxure ™ Control Expert, Operating Modes).

Index



В	G
BMXXSP0400, <i>32</i>	grounding accessories, 32
BMXXSP0600, <i>32</i>	BMXXSP0400, <i>32</i>
BMXXSP0800, <i>32</i>	BMXXSP0600, <i>32</i>
BMXXSP1200, <i>32</i>	BMXXSP0800, <i>32</i>
	BMXXSP1200, <i>32</i>
C	STBXSP3010, <i>32</i>
	STBXSP3020, <i>32</i>
certifications, 22	
channel data structure for all modules T_GEN_MOD, <i>85</i>	I
channel data structure for SSI modules	Input filtering, 41
T_SSI_BMX, <i>86</i>	
	M
D	MOD FLT, <i>96</i>
Device DDT	mounting the terminal block, <i>26</i>
T_M_SSI_3, <i>92</i>	
	Р
E	parameter settings, <i>73</i>
Electromagnetic interference, 30	parameter settings, 73
Example	
Introduction, 102	Q
Mouting the Module, 106	quick start
Requirements, 102	SSI Module BMX EAE 0300 Implementa-
Transfer a project, 116	tion Example, 99
-	
F	S
function	SSI interface, 48
Capture, 53	standards, 22
Modulo and Reduction, 49	STBXSP3010, <i>32</i>
Offset, 50	STBXSP3020, <i>32</i>

Т

T_GEN_MOD, 85 T_M_SSI_3, 92 T_M_SSI_CH_PRM, 98 T_M_SSI_CH_STS, 97 T_M_SSI_STD_CH, 93 T_SSI_BMX, 86