

INSTRUCTION

SHX

SHXI/SHPI

STAIL

6030



6031

LED



REGIOLUX

Regiolux GmbH
Hellinger Str. 3
D-97486 Königsberg/Bay.
T 09525 89-0
<http://www.regiolux.de>
info@regiolux.de









Achtung:
Leuchte nicht öffnen!
Garantieverlust!

Attention:
Don't open the luminaire!
Loss of Guarantee!



Attention:
N'est pas ouvrir le luminaire!
Perte de garantie!

Atención:
Non abrir la luminara!
Pérdida de garantía!





DALI**+SAY-KS 9511 1200 101****+SAY-KL 9510 1200 101**

- Ein / Aus / Dimmen -
- On / Off / Dimming -



- Ein / Aus / Tast-Dim -
- On / Off / Touch dim -

**M5S5****+SAY-KS 9511 1200 101****+SAY-KL9 9510 1209 101**

- Ein / Aus / Tast-Dim / Tageslichtregelung / Bewegungs- und Präsenzerkennung / Fernbedienung -
- Directes und indirektes Licht kann getrennt oder gemeinsam gesteuert werden.

- On / Off / Touch dim / Daylight control / Motion and presence detection / Remote control -
- Direct and indirect light can be controlled separately or together.

