


INSTRUCTION



SDT-System

SDT	182 .
SDCS	1890 0034 100
SDCSE	1890 0044 100
SDH	1890 0039 100
SDD	1890 0033 100
SDCT	1890 0042 100
SDTAF-7	1820 3092 100
SDTAF-11	1820 2092 100


IP20	
SDG	1820 100
SDGV	1820 150
SDGVL-LED	1821 150
SDGLK-LED	1823 100
SDBK	1883 7580 100
SDTE	1890 0231 100
SDTV	1820 0020 100
SDTVL	1820 0031 100

IP40	
SDGV-LED	1820 150


IP54	
SDGS	1846 100
SDGFF	1844 100
SDGS-LED	1846 100
SDBAS	1882 6580 100
SDTES	1890 0235 100
SDTVLS	1820 0050 100

REGIOLUX GmbH
D-97484 Königshausen/Bay.
Telefon (0 95 25) 89-0
Telefax (0 95 25) 89 73 4
http://www.regiolux.de
e-Mail: info@regiolux.de


IP20/54/40




SDT






IP20



IP54



IP40



REGIOLUX

