## Single key with 'I' and 'o' symbols for wireless switch or push button with two control buttons, cream

## 100-00002

4 year warranty

Single key with 'l' and '0' symbols for a wireless switch or bus push button with two control buttons. Finishing colour: cream.

## **Technical data**

Single key with 'I' and 'O' symbols for wireless switch or push button with two control buttons, cream.

- Number of control buttons: 1 control button
- Material central plate: The central plate is made of rigid PC and ASA. The base material is coloured in mass.
- Colour: cream (coloured in mass, approximately NCS S 1005 Y10R, RAL 1013)
- Print: Each key on the central plate is printed with the symbols "I" and "O" in indelible print.
- Dismantling: To dismount simply pull the central plate off the mechanism.
- Protection degree: IP41 for the combination of a mechanism, central plate and faceplate
- Impact resistance: After mounting, an impact-resistance of IK06 is guaranteed.
- Fire safety
  - The plastic parts of the central plate are self-extinguishing (comply with a filament test of  $650^\circ\text{C}$ )
- The plastic parts of the central plate are halogen-free.
- Dimensions of finishing: 45 x 45 mm (HxW)
- Dimensions (HxWxD): 44.5 x 44.5 x 8.6 mm
- Marking: CE







www.niko.eu