Double key with 'up' and 'down' arrows for wireless switch or push button with 4 control buttons, bronze

123-00010



A double key with the symbols up and down, for a bus push button with 4 control buttons. Finishing colour: bronze.

Technical data

Double key with 'up' and 'down' arrows for wireless switch or push button with 4 control buttons, bronze.

- Function: Finishing set for a Nikobus bus push button or a RF wall transmitter.
- Number of control buttons: 2 control buttons
- Material central plate: The central plate is enamelled and made of rigid PC and ASA.
- Colour: enamelled bronze (approximately NCS S 5005 Y20R, RAL 080 50 05)
- Print: Each key on the central plate is printed with the symbols "up" and "down" in indelible print.
- Dismantling: To dismount simply pull the central plate off the mechanism.
- Protection degree: IP41 for the combination of a mechanism, central plate and faceplate
- Impact resistance: After mounting, an impact-resistance of IK06 is guaranteed.
- Fire safety
 - The plastic parts of the central plate are self-extinguishing (comply with a filament test of 650°C)
 - The plastic parts of the central plate are halogen-free.
- Dimensions of finishing: 45 x 45 mm (HxW)
- Dimensions (HxWxD): 44.5 x 44.5 x 8.6 mm
- Marking: CE



