## Single push button with LED for Niko Home Control dark brown

## 124-52001



You can perform one operation with this push button. It is attached to the wall-mounted printed circuit board via a click mechanism. An LED indicates whether the light is switched on or off. Switch including button. Finishing colour: dark brown.

## **Technical data**

Single push button with LED for Niko Home Control dark brown.

- Material central plate: The central plate is enamelled and made of rigid PC and ASA.
- Lens: The key on the push button is fitted at the bottom with a small amber-coloured LED  $(1.5 \times 1.5 \text{ mm})$  to indicate the status of the action.
- Colour: enamelled dark brown (approximately NCS S 8505 Y20R, RAL 060 30 05)
- Fire safety
  - The plastic parts of the central plate are self-extinguishing (comply with a filament test of 650°C)
  - The plastic parts of the central plate are halogen-free.
- Input voltage: 26 Vdc (SELV, safety extra-low voltage)
- Dismantling: To dismount simply pull the push button off the wall-mounted printed circuit board.
- Impact resistance: After mounting, an impact-resistance of IK06 is guaranteed.
- Dimensions (HxWxD): 44.5 x 44.5 x 8.6 mm
- Marking: CE



