# **Conventional** Call Systems



## 800 SERIES

### 800 SERIES INFRARED TRANSMITTERS For use with infrared call points and ceiling receivers

Order Code	Description
QT412RXA	Infrared transmitter, rechargeable (push/pull for emergency)
QT412RXCA	Infrared transmitter, rechargeable (push for stnd/pull for emgcy)
QT424/1	Single-way charging unit for QT412 range transmitters
QT424/10	Ten-way charging unit for QT412 range transmitters
NC432	Infrared neck pendant transmitter (push for call), battery operated
NC432W	Infrared wrist pendant transmitter (push for call), battery operated



### 800 SERIES RESET POINTS Can be used to reset devices which do not have an onboard reset facility

Order Code	Description
NC809DB	Button reset point
NC809DBB	Button reset point c/w sounder and braille label
NC809DB/SS	Button reset point, s/steel
NC809DM	Magnetic reset point
NC899IRR	Keyswitch reset point
NC809DBBT	Accessible toilet reset point c/w sounder



### 800 SERIES ANCILLARY CALLING DEVICES Generate standard calls via a call point's remote socket

Order Code	Description
NC805C/6	1.8m (6ft) tail call lead
NC805C/14	4.2m (14ft) tail call lead
NC805D	1.2-3.6m (4-12ft) tail call lead
NC805P	Hand/foot pneumatic pad, requires 1 x NC805AS
NC805AS	Remote air switch for NC805P
NC805MD	Portable movement detector
NC644	Floor pressure mat
NC805DSP	Double remote jack socket



#### **MISCELLANEOUS 800 SERIES DEVICES**

Order Code	Description
NC803M/10	10 x magnetic reset keys (use to reset magentic call/reset points)
NC889	Call latch module (can trigger a std call from a n/o or n/c switch)
NC889ERM	Multi-purpose call latch module (can trigger std and/or emgy call from a n/o or n/c switch).
NC899KD	Area isolator (use to isolate areas/zones)
NC884DE	Emergency 5:1 input expander (use to provide area/zonal indication)
NC885	Standard 5:1 input expander (use to provide area/zonal indication
NC883D	12V relay unit (use to switch sirens, strobes, etc)

