

Nebula™ High Output

Installation guide for Nebula™ High Output Downlight



Important information

- It is recommended that luminaires are installed by a qualified electrician to ensure the installation complies with the local current wiring regulations.
- Any broken or damaged parts should be replaced as soon as possible. JCC will not accept responsibility for claims arising from sub-standard installations.
- It is recommended that the ambient room temperature should not exceed 30°C.
- These products are designed for connection to a mains supply of 200-240V~ 50Hz.
- The light source of this luminaire is not replaceable: when the light source reaches the end of its life the whole of the luminaire must be replaced.
- This luminaire is suitable for indoor use only.
- It may be necessary to upgrade your MCBs to allow for increased inrush current.
- For dimming guidelines please go to: jcc.co.uk/dimming
- DO NOT COVER the fitting with insulation as indicated by this symbol  on the luminaire.

INSTALLATION

ENGLISH

- Read the instructions and ensure that you have all of the tools and accessories required to complete the installation correctly. Isolate power supply before starting the installation.

Specification

Ra: 80

Wattage	Colour Temp	Lumens	LpcW
8W	3000K	770	97
8W	4000K	840	105
10W	3000K	820	82
10W	4000K	890	89
13W	3000K	950	73
13W	4000K	1200	92

Finishes available: White only

Fig.1a Cut Out Size

8W	10W	13W
Ø68-75MM	Ø90-95MM	Ø90-95MM

200-240V 50Hz / Class II 

Fig.2a Mains Input



Installation

- Cut the mounting hole in the ceiling. (JCC recommends that a sample hole is cut in a section of spare material to familiarize yourself with the process) see Fig.1a.
- Connect the mains supply as indicated in Fig.2a & Fig.2b.
- Place fitting into ceiling void (Fig.3).
- Reconnect mains power supply and test for operation.

Fig.2b






Fig.3




Important warranty information

This luminaire is supported by a 5 year extended warranty; which must be registered online at jcc.co.uk/warranty.


The installer will be asked to provide the following information, which is detailed on a label attached to the luminaire's chassis: Product Code/Batch Code.

Profile & Dimensions


8W Standard




10W & 13W Standard



8W Tilt



10W & 13W Tilt



All dimensions in millimetres

jcc.co.uk

JCC Lighting Products Ltd., Innovation Centre, Beeding Close, Southern Cross Trading Estate, Bognor Regis, West Sussex,
PO22 9TS, United Kingdom

Technical Support: +44(0)1243 838986
Customer Services: +44(0)1243 838999