

Switches

Pull Switches



707C

- Pull Switch
- 6 Amp
- Chrome



708

- Pull Switch
- 2 Amp
- White Pull Cord and Toggle



709

- Pull Switch
- 2 Amp
- Centre Pull
- White Pull Cord and Toggle



708C

- White Pull Cord For 708



708S

- Insulating/Isolating Shroud for 708

Door Switches



140WB

- Flush Mounting
- Push to Break
- C/W Back Box
- 1 Amp/230 Volt
- Brass Plate



140AWB

- Flush Mounting
- Push to Make
- C/W Back Box
- 1 Amp/230 Volt
- Brass Plate



140WBC

- Flush Mounting
- Push to Break
- C/W Back Box
- 1 Amp/230 Volt
- Chrome Plate



140AWBC

- Flush Mounting
- Push to Make
- C/W Back Box
- 1 Amp/230 Volt
- Chrome Plate



140LP

- Flush Mounting
- Push to Break
- 1 Amp/230 Volt
- Brass Plate



140ALP

- Flush Mounting
- Push to Make
- 1 Amp/230 Volt
- Brass Plate



140LPC

- Flush Mounting
- Push to Break
- 1 Amp/230 Volt
- Chrome Plate



140ALPC

- Flush Mounting
- Push to Make
- 1 Amp/230 Volt
- Chrome Plate



140 BOX

- Back Box for Flush Models 140LP, 140ALP, 140LPC & 140ALPC