



MPN: NLLRBPGB

Product Name: 1 Gang Flush/Surface Push To Make Exit Dome Button

Brand: Newlec

Category: Door Locks & Accessories

Product Description: Press the button in order to deactivate the electromagnetic lock on the door in order to exit. It features normally open and closed contacts, and can fit into a single gang back box. This button is designed for use with access control keypads and has an easy-to-clean surface. It is suitable for indoor use only.

Key Features:

- Surface mounted.
 - Normally open and closed contacts.
 - Will fit into single gang back box.
 - Press to exit.
 - Push to make.
 - For use with access control keypad.
 - Easy clean surface.
 - Indoor use only.
-

Specifications:

- Material: Plastic
- Mounting method: Surface mounted
- Colour: White

ETIM Class-9.0: Doorbell (EC000132)

ETIM Features:

- Material: Plastic (EV000139)
- Mounting method: Surface mounted (EV000384)
- Shape: Other (EV000154)
- Colour: White (EV000202)
- Wireless: No
- Length (mm): 30
- Width (mm): 85
- Height (mm): 85

Applications:

- This exit dome button is commonly used in access control systems for doors.



Unlock exclusive deals and discover a world of innovative solutions by scanning our QR code and visiting Rexel's website today!