



ACCESSORY FIXING SCREWS M3.5mm

		PACK QTY	
Platinum long fixing screw 50mm		100	735050
20mm long (vandal resistant)		100	735009/*/VR
25mm long (vandal resistant)		100	735010/*/VR
30mm long (vandal resistant)		100	735011/*/VR
25mm long	735010*	20mm long	100 735032
30mm long	735011*	23mm long	100 735038
50mm long	735012*	25mm long	100 735033
40mm long	735013*	30mm long	100 735023

* Add finish required i.e.735010SC.



SUNDRY SCREWS & SPACERS

		PACK QTY	
Rockergrid switch to grid		100	706124
Capital 50A switch to grid & grid to box	4950/BG series	100	735006/ZP
Rockergrid grid to box		100	735007
Capital plate to box on	4214 & 4216 ranges	100	735008/*
Rockergrid plate to grid		100	705094/*
Rockergrid plate to grid (vandal-resistant)		100	705094/*/VR
Screwdriver for Rockergrid VR screws		1	6913

*All screws are available to match the appropriate Capital Metal Plate and Rockergrid finishes.




CAPITAL CEILING SWITCH ACCESSORY ITEMS

1.5m long white pull cord and acorn	6900
2m long red pull cord and acorn	6900/1RD
2m long white pull cord with red acorn	6900/1WH
100m ball of white pull cord	6900/2
100m ball of red pull cord	6900/2RD
Ceiling switch acorn red	7410/RD
Ceiling switch acorn white	7410/WH



CAPITAL NEON INDICATORS

For 13A moulded & metal plate sockets, 13A fuse connection units, 20A, 32A, 45A capital switches	3713
For 13A safety sockets & slimline cooker control units	100215



CAPITAL NEON LENSES

For all 50A DP switches & large plate cooker control unit (larger lens) & 32A TP & N switches	3467
For 13A moulded & metal plate sockets, fuse connection units, 20A capital switches & slimline cooker control unit (smaller lens)	3711
For slimline cooker control unit (large lens) & capital 45A switches	3767
For 50A ceiling switch & large plate cooker control unit (smaller lens)	4674