


13A FUSED CONNECTION UNITS

LIST NO	DESCRIPTION CARTON	N QTY
VX1081 VX1081F** VX1090	DP switched DP switched with flex outlet & cord grip DP switched with neon DP switched with neon, flex outlet & cord grip Unswitched Unswitched with flex outlet & cord grip	10 10 10 10 10 10

- BS1363
- Terminals suitable for 3x2.5mm² or 2x4.0mm² conductor



13A SOCKET OUTLETS

LIST NO	DESCRIPTION	CARTON QTY
VX9100** VX9200** VX1300* VX1300/D _ VX1500 _ * VX1500/D _ VX1400 **	1 gang unswitched socket 2 gang unswitched socket 1 gang SP switched socket 1 gang DP switched socket 2 gang SP switched socket 2 gang DP switched socket 1 gang SP switched socket 1 gang SP switched socket	10 5 10 10 5 5
VX1600**	2 gang SP switched socket with neon	5

- BS1363
- Terminals suitable for up to 3x2.5mm² or 2x4.0mm² conductors
 2 gang DP sockets come with twin earth as standard



ROUND PIN SOCKET OUTLETS

LIST NO	DESCRIPTION	CARTON QTY
VX9905	15A switched socket, 1 gang, SP 5A switched socket, 1 gang, SP 2A 3 pin socket	10 10 10

BS546



45A DP CONTROL SWITCHES

LIST NO	DESCRIPTION	CARTON QTY
VX9712*	1 gang 45A DP Switch with neon	1
VX9713	1 gang 45A DP Switch	1
VX9702**	2 gang 45A DP Switch with neon	1
VX9703	2 gang 45A DP Switch	1



45A COOKER CONTROL UNIT

LIST NO	DESCRIPTION	CARTON QTY
VX9701**	Cooker Control Unit	1
VX9700	Cooker Control Unit with neon	1

- BS4177, BS1363
- Terminals suitable for up to $1 \times 16 \text{mm}^2$ conductors

Metal plate accessories are available in the following finishes: **SS** - Brushed Stainless Steel; **SB** - Satin Brass; **PS** - Polished Stainless Steel **APC** - Angled Polished Chrome; **RBB** - Round Edge Brushed Brass; **RBN** - Round Edge Black Nickel. Indicate the finish you require by adding the suffix to the list number; eg VX1080**SS**

- Only available in Black Nickel, Brushed Brass and Polished Chrome
- ** Only available in Stainless Steel and Polished Steel

