



4216/3BG

13A 2 GANG SWITCHED SOCKET OUTLETS

BS 1363-2	PACK QTY	
2 gang SP	10	4216/BG
2 gang SP with neon indicator	10	4216/3BG
2 gang DP	10	4216/DBG
2 gang DP with neon indicator	10	4216/3DBG



4216/BG/RD

13A 2 GANG SWITCHED SOCKET INTERIOR

BS 1363-2	PACK QTY	
2 gang SP with Red Rocker	10	4216/BG/RD



9687/BG

13A 2 GANG UNSWITCHED SOCKET OUTLETS

BS 1363-2	PACK QTY	
2 gang unswitched	10	9687/BG



2272/BG

15A 1 GANG SWITCHED SOCKET OUTLETS

BS 546	PACK QTY	
1 gang 15A shuttered SP	10	2272/BG



2240/BG

5A 1 GANG SWITCHED SOCKET OUTLETS

BS 546	PACK QTY	
1 gang 5A shuttered SP	10	2240/BG