



PLATINUM GRID




Complete Assembly



GRID PLATE - FLAT PLATE

	PACK	QTY
Plate for 1 gang grid	10	8711/_ _
Plate for 2 gang grid	10	8712/_ _
Plate for 3 gang grid	10	8713/_ _
Plate for 4 gang grid	10	8714/_ _
Plate for 6 gang grid	10	8716/_ _
Plate for 8 gang grid	10	8718/_ _

Available in Stainless Steel (**SS**), Polished Brass (**PB**) and Polished Stainless Steel (**PSS**)



GRID YOKES

	PACK	QTY
1 gang Yoke	10	1901
2 gang Yoke	10	1902
3 gang Yoke	10	1903
4 gang Yoke	10	1904
6 gang Yoke	10	1906
8 gang Yoke	10	1908

When mounting grid yokes for use with the flat plate remove the outer fixing ears



GRID SWITCHES-NO OUTER TRIM

BS EN 60669-1	PACK	QTY
10AX 1 way	10	4430/7_ _
10AX 2 way	10	4530/7_ _
10A Retractive	10	4489/7_ _
10A Retractive-Bell symbol	10	4490/7_ _
10A Retractive 2 way and Off	10	4553/7_ _
20AX 1 way	10	4450/7_ _
20AX 2 way	10	4550/7_ _
20AX Double Pole	10	4460/7_ _
20AX Intermediate	10	4535/7_ _
20AX 2 way & Off	10	4552/7_ _

Available in Polished Brass (**PB**), Stainless Steel (**SS**), and Polished Stainless Steel (**PSS**)

Installation Box depth 35mm

GRID KEY SWITCHES-NO OUTER TRIM

BS EN 60669-1	PACK	QTY
20AX 1 way Grid Key Switch	10	4451/7/WH*
20AX 2 way Grid Key Switch	10	4551/7/WH*
20AX DP 1 way Grid Key Switch	10	4461/7/WH*

* For Key Switches marked 'Emergency Light Test' Please add '**ELT**' to the List No. eg. **4451/7/WH/ELT**

• For Key Switches with a black front moulding, please remove the /WH from the List No. eg. **4451/7**.

For dimensions please see page 146

For material specification please see page 123-124