



7012/WH



5532/WH

32A DP CONTROL SWITCHES

BS EN60669-1 PACK QTY

COMPLETE ASSEMBLY

32A DP Switch	1	7012/WH
32A DP Switch + neon	1	7012/3WH

CONTROL SWITCH PLATES ONLY

32A DP Switch Plate	20	5532/WH
32A DP Switch + neon Plate	20	5532/3WH

For technical information please see page 112



7015/3WH



5545/3WH

45A DP CONTROL SWITCHES

BS EN60669-1 PACK QTY

COMPLETE ASSEMBLY

45A DP Switch	1	7015/WH
45A DP Switch + neon	1	7015/3WH


CONTROL SWITCH PLATES ONLY

45A DP Switch Plate	20	5545/WH
45A DP Switch + neon Plate	20	5545/3WH

For technical information please see page 113



7521/WH
5546/WH



45A COOKER CONTROL UNIT

BS 4177 & BS 1363-2 PACK QTY

COMPLETE ASSEMBLY

45A 2 Gang Cooker Control Unit	1	7521/WH
--------------------------------	---	---------

CONTROL UNIT PLATE ONLY

45A 2 Gang Cooker Control Unit	20	5546/WH
--------------------------------	----	---------

For technical information please see page 113



7411/WH



5510/WH

DUAL SHAVER SOCKET

BS EN61558-2-5 PACK QTY

COMPLETE ASSEMBLY

Shaver supply unit 240V	1	7411/WH
-------------------------	---	---------


SOCKET PLATE ONLY

Shaver Supply Unit Plate	20	5510/WH
--------------------------	----	---------

For technical information please see page 114



7765/WH



5565/WH

DATA ACCESSORIES

BS 3041 PACK QTY

COMPLETE ASSEMBLY

Single Co-Axial direct connection	1	7765/WH
-----------------------------------	---	---------

CO-AXIAL PLATE ONLY

Co-Axial Plate	20	5565/WH
----------------	----	---------

For technical information please see page 115



7783/WH



5583/WH

TELEPHONE ACCESSORIES

BS 3041 PACK QTY

COMPLETE ASSEMBLY

Single BT Secondary	1	7783/WH
Single BT Master	1	7784/WH

TELEPHONE PLATE ONLY

BT Master & Slave Plate	20	5583/WH
-------------------------	----	---------

For technical information please see page 116

For dimensions please see page 144
For material specification please see page 123-124