



VX9712



VX9700



VX9713



VX9701



VX9704



VX9702



VX1020



VX1040



VX1050



VX1051



VX1054



VX4020



VX4000

45A Double Pole Control Switch

LIST NO	DESCRIPTION
VX9712	45A DP switch with neon
VX9713	45A DP switch
VX9702	45A DP switch with neon (large plate)
VX9703	45A DP switch (large plate)

45A Cooker Control Units

LIST NO	DESCRIPTION
VX9700	45A CCU with 13A switched socket & neon
VX9701	45A CCU with 13A switched socket

- Terminals suitable for up to 1 x 16mm² cable
- Double pole switching on both 45A & 13A circuits
- Markings to customer specification available

Cooker Outlet Plate

LIST NO	DESCRIPTION
VX9704	Cooker outlet plate with pillar terminals

- 1 gang 85mm x 85mm
- 2 gang & Cooker Control Units 85mm x 145mm

Product Standard

45A Switches BS EN 60669-1
 Cooker Control Units BS 4177, BS 1363
 Cooker Outlet Plates BS 5733

Installation Boxes

Cooker Outlet Plate	
SB615	1 Gang Flush 35mm
Cooker Control Switch	
SB618	1 Gang Flush 47mm
SB628	2 Gang Flush 47mm
VX9405	1 Gang Surface 42mm
VX9416	2 Gang Surface 35mm

10AX Wall Switches

LIST NO	DESCRIPTION
VX1010	1 gang 1 way switch
VX1020	1 gang 2 way switch
VX1030	1 gang intermediate switch
VX1040	2 gang 2 way switch
VX1041	2 gang 1 way switch
VX1050	3 gang 2 way switch
VX1051	3 gang 1 way switch
VX1054	4 gang 2 way switch

- Terminals suitable for 4 x 1.0mm², 3 x 1.5mm² or 1 x 2.5mm² conductors

10AX Wide Rocker Switches

LIST NO	DESCRIPTION
VX4020	1 gang 2 way switch
VX4030	1 gang Intermediate switch
VX4040	2 gang 2 way switch
VX4000	Retractive switch

- 1–3 Gang 85mm x 85mm, 4 Gang 145mm x 85mm

Product Standard

BS EN 60669-1

Installation Boxes

VX9404	Surface Moulded 1–3 gang	VX9401	Surface Moulded 1 gang
VX9412	Surface Moulded 4 gang	VX9402	Surface Moulded 2 gang
SB623	Flush Metal 1–3 gang	9257	Flush Metal 1 gang
SB665	Flush Metal 4 gang	9258	Flush Metal 2 gang