

Hearing Loop Systems



CONNECTION LEADS

Order Code	Description
AL1	3.5mm jack to 3.5mm jack lead
AL2	3.5mm jack to double phono lead
AL3	3.5mm jack to bare ended lead (connects FPROSG to PDA103, ML1, PDA200E)
AL4	XLRM to 6.35mm mono jack lead
AL5	XLRM to XLRF balanced lead
AL6	3.5mm to 6.35mm convertor plug
AL7	2.5mm Power plug 1.8m lead
AL8	Fused car lighter PSU
AL9	3.5mm Stereo jack plug 2m lead
AL12	3.5mm plug to 6.35mm jack socket
AL14	Male XLRM to 3.5mm jack lead (connects FPROSG to PDA-PRO)
AL15	Stereo to unbalanced mini jack lead (connects SigGen To DLR kits)
AXLR	XLR to XLR lead (used to connect AMP mic to APXM outreach plate)



APS

HEARING LOOP CABLE

Order Code	Description
LOOP1/W	100m x 0.5mm ² single core white loop cable
LOOP2/W	100m x 1.0mm ² single core white loop cable
LOOP3/W	100m x 1.5mm ² single core white loop cable
LOOP4/W	100m x 2.5mm ² single core white loop cable
FLAT2005	100m x 1.0 mm ² insulated copper tape (flat loop cable for under carpets)
FLAT3005	100m x 1.5mm ² insulated copper tape (flat loop cable for under carpets)
FLAT4005	100m x 2.5mm ² insulated copper tape (flat loop cable for under carpets)
TAPE/P	50m printed hearing loop foil loop tape

LOOP2/W



FLAT2005

Note loop cable is included in ML1/K & PDA103 hearing loop kits.

MISCELLANEOUS HEARING LOOP EQUIPMENT

Order Code	Description
APT	Loop connector plate (for the termination of hearing loop cable)
LEST	100V line (i.e PA system output) to 0db (775mV line level) convertor
APPS	Overspill reduction phase shifter
TEAR-P	Spare 'AFILS available' sticker
TEAR10	Pack of 10 self-adhesive 'hearing loop fitted' stickers
TEARA4	Large 'AFILS available' sign (A4)