

**18MS14**

MAIN SWITCH UNITS

Total MCB / RCBO Ways	Main Switch Rating	LIST No
2	63A	18MS2
5	100A	18MS5
8	100A	18MS8
8	63A	18MS8/63
11	100A	18MS11
14	100A	18MS14
19	100A	18MS19

Supplied with Main Switch and busbar

Single Module RCBOs are not recommended for use within 2 way units

**18MRSL12**

FLEXIBLE SPLIT LOAD UNITS

Total Ways	100A Main Switch	80A 30mA RCCB	LIST No
9	3 to 6	3 to 6	18MRSL09
12	3 to 9	3 to 9	18MRSL12
17	5 to 12	5 to 12	18MRSL17

Supplied with Main Switch, DP RCCB and busbars

Both MCBs and RCBOs may be included for final circuit positions that are not protected by the resident RCCB

**18MSHI10**

FLEXIBLE HIGH INTEGRITY DUAL RCD UNITS

Total Ways	100A Main Switch	80A 30mA RCCB 1	80A 30mA RCCB 2	LIST No
10	2 to 5	2 to 5	2 to 5	18MSHI10
15	2 to 5	2 to 9	2 to 9	18MSHI15

Supplied with Main Switch, two DP RCCBs and busbars

Both MCBs and RCBOs may be included for final circuit positions that are not protected by resident RCCBs

**18MSDR10**

FLEXIBLE DUAL RCD SPLIT LOAD UNITS

Total MCB Ways	100A Main Switch	80A 30mA RCCB 1	80A 30mA RCCB 2	LIST No
10	-	4 to 6	4 to 6	18MSDR10
15	-	6 to 9	6 to 9	18MSDR15

Supplied with Main Switch, two DP RCCBs and busbars

Both MCBs and RCBOs may be included for final circuit positions that are not protected by resident RCCBs

For replacement surface lid assemblies see page 7

For flush mounting kits see page 7