

FUSESTAR HOUSED FUSE COMBINATION UNITS 20A-400A



FUSE COMBINATION UNIT 20A–32A

20A	SP&N	supplied	190201NF
	TP&N	with	190203NF
	4P	20A fuses	190204F
32A	SP&N	supplied	190321NF
	TP&N	with	190323NF*
	4P	32A fuses	190324F
Accessories	Cable Spreader Box		19032CSB
	Copper Isolator Link Each		19LK32
Modular width			4
Terminals	20A–32A	16mm2 Max	Cable Clamp
Spreading room		up to 10mm2 4 Core *	



FUSE COMBINATION UNIT 63A–100A

63A	SP&N	supplied	190631NF
	TP&N	with	190633NF*
	4P	63A fuses	190634F
100A	SP&N	supplied	191001NF
	TP&N	with	191003NF*
	4P	100A fuses	191004F
Accessories	Cable Spreader Box		19100CSB
	Copper Isolator Link Each 63A		19LK63
	Copper Isolator Link Each 100A		19LK200
	Castell Lock (factory fitted)		Suffix CLK
Modular width			5
Terminals	63A–100A	63A-Cable Clamp 25mm ²	
		100A- M8 Hole	
Spreading room		up to 70mm ² 4 Core *	
Cable lug palm copper size		20mm wide Maximum	