

FUSESTAR HOUSED FUSE COMBINATION UNITS 20A-400A



FUSE COMBINATION UNIT 125A–200A

125A	SP&N	supplied	191251NF
	TP&N	with	191253NF
	4P	125A fuses	191254F
160A	SP&N	no	191601N
	TP&N	fuses	191603N*
	4P	supplied	191604
200A	SP&N	no	192001N
	TP&N	fuses	192003N
	4P	supplied	192004
Accessories	Cable Spreader Box		19200CSB
	Copper Isolator Link Each		19LK200
	Castell Lock (factory fitted)		Suffix CLK
Modular width			6
Terminals			125A–200A M8
Spreading room			up to 150mm ² 4 Core *
Cable lug palm copper size			20mm wide Maximum



FUSE COMBINATION UNIT 315A–400A

315A	TP&N	no fuses	193153N*
	4P	supplied	193154
400A	TP&N	no fuses	194003N
	4P	supplied	194004
Accessories	Cable Spreader Box		19400CSB
	Copper Isolator Link Each		19LK400
	Castell Lock (factory fitted)		Suffix CLK
Modular width			8
Terminals			315A–400A M10
Spreading room			up to 300mm ² 4 Core *
Cable lug palm copper size			45mm wide Maximum

* Spreading Room is allowed for at one end only. To fit a 4 core cable at both ends an additional Cable spreader box will be required. 1 Module = 52.5mm