




DINRAIL, ROWBOARD, SERVICE CENTRES

Service Centre/DIN Rail Board:	List No
18 Module	18PSCDIN18
36 Module (2 Rows of 18)	18PSCDIN36

- 'Add-On' for fixture above or below surface type B board.
- Equipped with easily removed DIN Rail to accommodate 18 or 36 18mm module wide DIN Rail mounted devices
- 245 & 410mm high

Cable Spreader Box

Add on Enclosure, 245mm high, Blank front cover plate	18PSCSB
---	----------------



Rowboard:



No of Rows	H	W	D	
1	245	430	155	18PSCAS1
2	410	430	155	18PSCAS2
3	570	430	155	18PSCAS3
4	735	430	155	18PSCAS4
5	815	430	155	18PSCAS5

- Suitable for 'Stand-Alone' use or 'Add-On' above surface type B board.
- Each row will accommodate 18 off 18mm module wide DIN Rail mounted devices.
- Main Neutral and Earth Bars included, along with provision for additional 'Mini' Neutral and Earth bars.



GENERAL POLESTAR ACCESSORIES TP & SP

	List No
Cylinder Lock & Key	16CL
MCB Locking device (excl. lock)	MCBLD
Padlock & Key for use with MCBLD	748
Clean Earth Bar Kit type B Boards only.	18CEBK
(4 to 12 way=1 kit, 16 to 24 way=2 kits).	
SP MCB size Blank (shields MCB & Busbar Terminal)	18PSCMBP1
Blanking Strip - 6 Individual 1 module wide pieces	18PSCBP1/6
Blanking Strip - 4 lengths each 3 modules wide	18PSCBP3/4
Blanking Strip - 2 lengths each 12 modules wide	18PSCBP12/2
Clip In Blank SP Moulding	CSBC
Busbar cross connector insulator - pack of 9	18PSCBB1
Cable clamp assembly (70mm ²) - pack of 3	17CC



ADDITIONAL EARTH BAR KITS

Additional Earth Bars to fit TP Distribution Boards

No of Ways	List No	No of Ways	List No
4	18EB04	16	18EB16
6	18EB06	20	18EB20
8	18EB08	24	18EB24
12	18EB12		

Earth and Neutral bar, 10mm² cable max, for use with DIN Rail

	NEUTRAL	EARTH
7 Terminals	CLNB07	CLEB07
12 Terminals	CLNB12	CLEB12
15 Terminals	CLNB15	CLEB15

