

ROCKERGRID 20AX MOULDED GRID SWITCHES



20AX SWITCHES – MOULDED ROCKER

BS EN 60669-1

4450	1 way
4451	1 way with key
4451/ELT	1 way with key marked "Emergency Lighting Test"
4460	Double Pole
4461	Double Pole with key
4461/ELT	DP with key marked "Emergency Lighting Test"
4469	DP marked 'ON'
4535	Intermediate
4535/KEY	Intermediate with key
4550	2 way
4551	2 way with key
4551/ELT	2 way with key marked "Emergency Lighting Test"
4552	2 way and off
6940	Spare key



20AX SWITCHES – BLACK OR RED MOULDED ROCKER

BS EN 60669-1

4450/BK or RD	1 way
4451/BK	1 way with key
4460/BK	Double Pole
4461/BK	Double Pole with key
4535/BK or RD	Intermediate
4550/BK or RD	2 way
4551/BK or RD	2 way with key
4552/BK or RD	2 way and off



20AX DOUBLE POLE SWITCH MARKING

BS EN 60669-1

4460/BO	boiler
4460/DW	dishwasher
4460/FR	fridge
4460/FF	fridge freezer
4460/HT	heating system
4460/TD	tumble dryer
4460/WDR	washer dryer
4460/WA	water heater
4460/HD	cooker hood
4460/EF	extractor fan
4460/FZ	freezer
4460/HB	hob
4460/MW	microwave
4460/WD	waste disposal
4460/WM	washing machine