
73

Euroflow_{TM}


Single Phase In-line Centrifugal Duct Fans

Wiring Diagrams 230V 1PH 50HZ Supply


Switch Spur Wiring Diagram



D.O.L. Starter Wiring Diagram




Single Phase Electronic Speed Controller Wiring Diagram



Single Phase In-line Centrifugal Duct Fans

Wiring Diagrams 230V 1PH 50HZ Supply

Single Phase Auto Transformer Speed Controller Wiring Diagram



These products must be installed by a suitably qualified and competent person in accordance with current applicable regulations.



72

