

Vent-Axia®


Solo Plus Bezel Fitting

READ IN CONJUNCTION WITH SOLO PLUS LEAFLET SUPPLIED WITH THE FAN
READ AND SAVE THESE INSTRUCTIONS

NOTE:- CUT-OUT ON INSIDE EDGE
OF BEZEL TO LINE UP WITH
SPIGOT OUTLET
ON THE FAN

1. PLACE BEZEL OVER HOLE
IN THE WALL.(SEE FAN INSTRUCTIONS
FOR POSITION AND SIZE).

2. PASS SOLO PLUS UNIT THROUGH
THE APERTURE IN THE BEZEL. (NOTE
CUT-OUT POSITION)



U.K NATIONAL TECHNICAL SUPPORT
Domestic & Commercial
Tel: 01293 441535
Fax: 01293 539209
Email:info@vent-axia.com

Vent-Axia®

Head Office: Fleming way, Crawley, West Sussex RH10 9YX
www.vent-axia.com