C-JS220-X C-JS220-X **BATTERY BATTERY**

CORDLESS JIGSAW

- · Cordless jigsaw for precise cuts in different materials, such as timber, metal, aluminium, brass, plastic etc. (when using a suitable saw blade)
- Cordless work with the Scheppach IXES 20 Volt series all batteries and chargers belonging to this system series can be combined with the cordless jigsaw
- Quick sawing progress, thanks to pendulum stroke adjustable in 3 steps and fine-cut adjustment
- 7 adjustable cutting angles (-45°, -30°, -15°, 0°, +15°, +30°, +45°)
- Safety switch with steplessly adjustable stroke, 0 2400 strokes per minute
- Foldable, removable, transparent **saw blade guard** allows safe work



SPECIFICATIONS

SPECIFICATIONS	
Dimensions L x W x H	240 x 220 x 75 mm
Motor type	Brush motor
Stroke rate	0 – 2400 rpm
Stroke length	19 mm
Pendulum stroke levels	1 – 3 and fine cut setting
Cutting angle	7 adjustable -45° / -30° / -15° / 0° / +15° / +30°/ +45°
Cutting depth max.	100 mm (timber), 6 mm (metal) 8 mm (plastic)
Battery voltage	20 V

LOGISTICAL DATA	
Weight net / gross	1.5 / 1.9 kg
Packaging dimensions	280 x 245 x 90 mm
Article number	5901817900
Barcode	4046664217787
20 Container	3640 pcs
40 Container	7680 pcs
40 HQ Container	9040 pcs



EXAMPLES OF USE SUITABLE FOR

Construction site Workshop





House





and fine cut setting











PRODUCT DETAILS

Saw blade length 145 mm



Stroke rate 0 - 2400 rpm



LED work light



Stroke length 19 mm

7 cutting angles -45° / -30° / -15° / 0°

/ +15° / +30° / +45°





20 V



UNIVERSAL USE







www. sound .com | Issue 2023-12-22 | Subject to technical change without notice. Errors and omissions excepted.