

GUIDE TO MAINTAIN YOUR MASTER PORTABLE EVAPORATIVE COOLER

STEP 1

Clean cooling pads with medium high pressure.

STEP 2

Drain all water from the water tank and clean, ensuring the pads and tank are completely dry.

STEP 3

Clean out the strainer located within the pressure regulator valve*. Remove the spray bar and clean out any debris. Reinstall after cleaning.

STEP 4

Disconnect and roll up any electrical power cords and any hoses so they are not trampled on, tripped over or caught in equipment.

STEP 5

Cover the Master cooler completely to prevent dust build-up and store the unit in a dry area. This also helps prevent damage to the pads for longer pad life.

For more information

Contact our experts for any additional question or spare parts required:
www.danthermgroup.com

Keep updated about solutions and get the best out of your cooler signing up for our newsletters



BC 341



BC 221



BC 121