




| - ₩ | 220 - 240 V~ |
|------------|---|
| M | 50 / 60 Hz |
| | 2 x 1,5 mm² Recommended use of a soft wire |
| | -20°C / +40°C |
| * | PIR |
| ₩ | 2 000 LUX |
| 9 | 10sec |
| | 12 m |
| \Diamond | IP 44 |







· Installation and connection:

Install the sensor in a suitable place where its performance will not be affected by direct hot air flow (e.g. from a heater), direct sunshine or other disturbing factors.

- 1. Select a suitable location, preferably across the monitored area, up to 2,5m in height.
- Switch off the main power supply, connect the wires according to the diagram and then connect the sensor to the junction box.
- 3. Use the switch to set the desired parameters of the sensor.

· Setting time (switch-off delay)

The desired operating time (lighting) of a light can be continuously adjusted within the range of 10 seconds +/- 5 seconds to 7 minutes +/- 120 seconds. Every motion during this period will trigger a new cycle. When adjusting the detection zone and testing the function, it is recommended to set the shortest time.

· Twilight setting (light sensitivity)

You can adjust the desired light sensitivity continuously within the range of approx. 3 LUX to 2 000 LUX.

Warning

This device should be installed by a qualified electrician in accordance with the latest edition of the IET wiring regulations.