SIEMENS

Data sheet

3RA2210-1DA15-2BB4



Load feeder fuseless, Reversing duty 400 V AC, Size S00 2.20...3.20 A 24 V DC screw terminal for installation on standard mounting rail (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NC (contactor)

product brand name product designation design of the product product type designation manufacturer's article number • of the supplied contactor

SIRIUS Reversing starter

for standard rail or screw mounting

3RA22

S00 S00

690 V

6 kV

other

6g / 11 ms 30 000 000

• of the supplied circuit-breakers • of the supplied link module

3RT2015-1BB42 3RV2011-1DA10

3RA1921-1DA00

General technical data

size of the circuit-breaker size of load feeder insulation voltage with degree of pollution 3 at AC rated surge voltage resistance rated value degree of protection NEMA rating shock resistance according to IEC 60068-2-27 mechanical service life (switching cycles) of contactor typical type of assignment type of protection according to ATEX directive

2 Ex II (2) GD

certificate of suitability according to ATEX directive 2014/34/EU

DMT 02 ATEX F 001

2014/34/EU

10/01/2009

Substance Prohibitance (Date)

Ambient conditions

ambient temperature	
 during operation 	-20 +60 °C
during storage	-50 +80 °C
 during transport 	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %

Main circui

number of poles for main current circuit	3	
design of the switching contact	electromechanical	
adjustable current response value current of th current-dependent overload release	ne 2.2 3.2 A	
operating voltage		
rated value	690 V	
 at AC-3 rated value maximum 	690 V	
 at AC-3e rated value maximum 	690 V	
operating frequency rated value	50 60 Hz	

operational current

at AC 2 at 400 V rated value	0.7 A
at AC-3 at 400 V rated value	2.7 A
• at AC-3e at 400 V rated value	2.7 A
operating power	
• at AC-3	4.400 M
— at 400 V rated value	1 100 W
at AC-3e — at 400 V rated value	1 100 kW
	I IOU KVV
Control circuit/ Control	
type of voltage of the control supply voltage	DC
control supply voltage at DC	
rated value	24 V
• rated value	24 24 V
holding power of magnet coil at DC	4 W
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	3.2 A
yielded mechanical performance [hp]	
• for 3-phase AC motor	
— at 200/208 V rated value	0.5 hp
— at 220/230 V rated value	0.75 hp
— at 460/480 V rated value	1.5 hp
— at 575/600 V rated value	2 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	magnetic
Conditional Short-circuit current (19)	
at 400 V according to IEC 60047-4-1 rated value	150 000 A
at 400 V according to IEC 60947-4-1 rated value	150 000 A
Installation/ mounting/ dimensions	
Installation/ mounting/ dimensions mounting position	vertical
Installation/ mounting/ dimensions mounting position fastening method	vertical screw and snap-on mounting onto 35 mm standard mounting rail
Installation/ mounting/ dimensions mounting position fastening method height	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm
Installation/ mounting/ dimensions mounting position fastening method height width	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — forwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards • upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — at the side	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — at the side Connections/ Terminals	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — torwards — backwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — torwards — backwards — upwards — backwards — upwards — torwards — torw	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for auxiliary and control circuit type of connectable conductor cross-sections	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — a the side — downwards • for live parts — forwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — a the side — downwards • for live parts — forwards — backwards — upwards — a the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts — stranded	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 50 mm 10 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — a the side — downwards • for live parts — forwards — a the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts — stranded • at AWG cables for main contacts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — torwards — backwards — backwards — upwards — the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts — stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 50 mm 10 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — a the side — downwards • for live parts — forwards — a the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts — stranded • at AWG cables for main contacts	vertical screw and snap-on mounting onto 35 mm standard mounting rail 170 mm 90 mm 97 mm 32 mm 0 mm 50 mm 10 mm

B10 value with high demand rate according to SN 31920 proportion of dangerous failures

• with high demand rate according to SN 31920

touch protection on the front according to IEC 60529

1 000 000

73 %

No

No

No

finger-safe, for vertical contact from the front

Communication/ Protocol

protocol is supported

• PROFINET IO protocol PROFIsafe protocol

protocol is supported AS-Interface protocol

Certificates/ approvals

General Product Approval

For use in hazardous locations

Declaration of Conformity



Confirmation









Declaration of Conformity

Test Certificates

Marine / Shipping



Type Test Certificates/Test Report

Special Test Certificate







Marine / Shipping







Confirmation

other

Vibration and Shock

Railway

Dangerous Good

Transport Informa-<u>tion</u>

Further information

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2210-1DA15-2BB4

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2210-1DA15-2BB4

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2210-1DA15-2BB4


Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RA2210-1DA15-2BB4&lang=en


Characteristic: Tripping characteristics, I2t, Let-through current


https://support.industry.siemens.com/cs/ww/en/ps/3RA2210-1DA15-2BB4/char


Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2210-1DA15-2BB4&objecttype=14&gridview=view1









last modified: 11/5/2022 🖸